DIN EN 474-11:2023-02 (E)

Earth-moving machinery - Safety - Part 11: Requirements for earth- and landfill compactors

Contents

Page

European foreword 3

Introduction 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 7

4 Safety requirements and/or protective/risk reduction measures 7
4.1 General 7
4.2 Operator's station 8
4.3 Seat 8
4.4 Steering system 9
4.5 Braking system 9
4.6 Stability 9
4.7 Lifting operation 9
4.8 Protective measures and devices 9

5 Verification of the safety requirements and/or protective/risk reduction measures 9

6 Information for use 10
6.1 General 10
6.2 Machine safety labels 10
6.3 Operator's manual 11

Annex A (informative) List of significant hazards 12

Annex B (normative) Braking requirements for earth- and landfill compactors 17

B.1 Terms and definitions 17
B.2 General requirements 17
B.3 Test conditions 17
B.4 Performance test 19

Annex C (informative) Illustrations 21

Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC machinery, and amending Directive 95/16/EC (recast) [2006 L157] aimed to be covered 22

Bibliography 27