ISO 10300-2:2023-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (macropitting)

Contents

Page

Foreword iv

Introduction vi

1 Scope 1

2 Normative references 1

3 Termsanddefinitions 1

4 Symbols, general subscripts and abbreviated terms 2

5 Macropitting damage -- General aspects 6
5.1 Acceptable versus unacceptable macropitting 6
5.2 Assessment requirements 6
5.3 General rating procedure 7

6 Gearflankratingformulae--MethodB1 7
6.1 Contact stress formula 7
6.2 Permissible contact stress 8
6.3 Calculated safety factor for contact stress 8
6.4 Contact stress factors 9
6.4.1 Mid-zone factor, ZM-B 9
6.4.2 Load sharing factor, ZLS 10
6.5 Permissible contact stress factors 11
6.5.1 Bevel gear factor, ZKP 11
6.5.2 Size factor, ZX 12
6.5.3 Hypoid factor, ZHyp 12

7 Gearflankratingformulae--MethodB2 15
7.1 Contact stress formula 15
7.2 Permissible contact stress 16
7.3 Calculated safety factor for contact stress 16
7.4 Contact stress factors 16
7.4.1 General 16
7.4.2 Macropitting resistance geometry factor, ZI 17
7.4.3 Facewidth factor, ZFW 20
7.4.4 Contact stress adjustment factor, ZA 20

8 Factorsforcontactstressandpermissiblecontactstresscommonformethod B1 andmethodB2 21
8.1 Elasticity factor, ZE 21
8.2 Lubricant film influence factors, ZL, Zv, ZR 21
8.2.1 General 21
8.2.2 Restrictions 21
8.2.3 Method B 21
8.2.4 Method C (product of ZL, Zv and ZR) 23
8.3 Work hardening factor, ZW 23
8.3.1 General 23
8.3.2 Work hardening factor, ZW: Method A 23
8.3.3 Work hardening factor, ZW: Method B 24

8.4 Life factor, ZNT 26
8.4.1 General 26
8.4.2 Method A 27
8.4.3 Method B 28

Annex A (informative)Localcalculationmethodforsurfacedurability(macropitting)- MethodB1-localised 29

Bibliography 35