

# ISO 16119-5:2023-11 (E)

## Agricultural and forestry machinery - Environmental requirements for sprayers - Part 5: Aerial spray systems

---

<b>Contents</b>	<b>Page</b>
Foreword.....	iv
Introduction.....	v
<b>1 Scope.....</b>	<b>1</b>
<b>2 Normative references.....</b>	<b>1</b>
<b>3 Terms and definitions.....</b>	<b>2</b>
<b>4 List of significant hazards.....</b>	<b>2</b>
<b>5 Requirements.....</b>	<b>3</b>
5.1 General.....	3
5.2 Sprayer tanks.....	3
5.2.1 Materials.....	3
5.2.2 Tank openings.....	3
5.2.3 Emptying.....	4
5.2.4 Tank contents indicator(s).....	4
5.2.5 Agitation.....	4
5.2.6 Filling pre-mix tank.....	4
5.3 Hoses and lines.....	5
5.4 Spray boom.....	5
5.4.1 Design and location.....	5
5.4.2 Adjustment.....	5
5.5 Safety measures.....	5
5.6 Filters.....	6
5.7 Nozzles/atomizers.....	6
5.8 Measuring systems.....	6
5.8.1 General.....	6
5.8.2 Provisions for connecting test equipment.....	7
5.9 Volume/area adjustment system.....	7
5.10 Distribution and control of spray drift.....	7
5.10.1 Distribution.....	7
5.10.2 Control of spray drift.....	8
5.10.3 Swathe marking/mapping.....	8
5.11 Cleaning.....	8
5.11.1 Cleaning devices at the sprayer.....	8
5.11.2 Water tanks.....	8
<b>6 Instruction handbook/Operator's manual.....</b>	<b>8</b>
<b>7 Markings.....</b>	<b>9</b>
<b>Annex A (informative) Guidelines, aerial deposition models and nozzle drop size category websites.....</b>	<b>10</b>
<b>Bibliography.....</b>	<b>11</b>