

# ISO/TS 19425:2024-07 (E)

## Reciprocating internal combustion engines - Measurement method for air cleaners - Sound power level of combustion air inlet noise and insertion loss using sound pressure

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b>		<b>iv</b>
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>1</b>
<b>4</b>	<b>Test environment</b>	<b>5</b>
4.1	General	5
4.2	Criterion for background noise	5
4.3	Criterion for acoustic adequacy of test environment	6
<b>5</b>	<b>Instrumentation</b>	<b>6</b>
5.1	General	6
5.2	Calibration	6
5.3	Application	7
<b>6</b>	<b>Installation and operation conditions</b>	<b>7</b>
6.1	General	7
6.2	Installation condition	7
6.3	Operation condition	8
<b>7</b>	<b>Measurement</b>	<b>9</b>
7.1	General	9
7.2	Measurement uncertainty	9
7.3	Characteristic source dimension	10
7.4	Measurement radius	10
7.5	Measurement surface and area	10
7.6	Microphone arrays	10
<b>8</b>	<b>Calculation</b>	<b>12</b>
8.1	General	12
8.2	Calculation of sound power level	12
8.2.1	Mean time-averaged sound pressure levels	12
8.2.2	Corrections for background noise	13
8.2.3	Corrections for environmental	13
8.2.4	Surface time-averaged sound pressure levels	14
8.2.5	Sound power levels	14
8.3	Calculation of insertion loss	14
<b>9</b>	<b>Information to be recorded</b>	<b>15</b>
<b>10</b>	<b>Test report</b>	<b>16</b>
<b>Annex A (normative)</b>	<b>Qualification procedures for the acoustic environment</b>	<b>17</b>
<b>Annex B (normative)</b>	<b>Calculation of A-weighted sound power levels from frequency band levels</b>	<b>20</b>
<b>Annex C (normative)</b>	<b>Sound power level under reference meteorological conditions</b>	<b>22</b>
<b>Bibliography</b>		<b>23</b>