

# DIN EN ISO 16122-3:2026-05 (E)

## Agricultural and forestry machinery - Inspection of sprayers in use - Part 3: Sprayers for bush and tree crops (ISO 16122-3:2024)

---

<b>Contents</b>		<b>Page</b>
Foreword.....		v
Introduction.....		vii
<b>1</b>	<b>Scope</b> .....	<b>1</b>
<b>2</b>	<b>Normative references</b> .....	<b>1</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>1</b>
<b>4</b>	<b>Requirements and method of verification</b> .....	<b>1</b>
4.1	General.....	1
4.2	Leaks and dripping.....	2
4.2.1	Static leaks.....	2
4.2.2	Dynamic leaks.....	2
4.2.3	Spraying and dripping on parts.....	2
4.3	Pump(s).....	2
4.3.1	Capacity.....	2
4.3.2	Pulsations.....	3
4.3.3	Air chamber.....	3
4.4	Spray mix agitation.....	3
4.4.1	Hydraulic.....	3
4.4.2	Mechanical.....	3
4.5	Spray tank(s).....	3
4.5.1	Lid.....	3
4.5.2	Tank filling strainer.....	4
4.5.3	Pressure compensation.....	4
4.5.4	Tank content indicator(s).....	4
4.5.5	Tank emptying.....	4
4.5.6	Tank filling.....	4
4.5.7	Induction hopper.....	4
4.5.8	Cleaning device for plant protection product containers.....	4
4.5.9	Cleaning equipment.....	5
4.6	Measuring systems, controls and regulation systems.....	5
4.6.1	General.....	5
4.6.2	Pressure indicator for spray liquid.....	5
4.6.3	Other measuring devices.....	6
4.6.4	Pressure adjusting devices.....	6
4.6.5	Pressure drop.....	6
4.6.6	Spray boom section pressure equalizer.....	6
4.7	Lines (pipes and hoses).....	6
4.7.1	Lines.....	6
4.8	Filters.....	6
4.8.1	Filter presence.....	6
4.8.2	Isolating device.....	7
4.8.3	Filter insert changeability.....	7
4.9	Nozzles.....	7
4.9.1	Nozzle arrangement.....	7
4.9.2	Dripping.....	7
4.9.3	Switching off.....	7
4.9.4	Adjustment.....	7
4.10	Distribution of pressure and spray liquid flow.....	7

4.10.1	Distribution of spray liquid.....	7
4.11	Blower.....	8
4.11.1	Condition.....	8
4.11.2	Adjustability.....	8
4.12	Spray guns and lances (if present).....	9
4.12.1	Trigger.....	9
4.12.2	Adjustment of flow rate and angle.....	9
<b>5</b>	<b>Test methods.....</b>	<b>9</b>
5.1	Test facilities and equipment.....	9
5.1.1	General.....	9
5.1.2	Test facilities.....	9
5.2	Pumps.....	9
5.2.1	Pump capacity test.....	9
5.2.2	Pump pulsations.....	10
5.3	Sprayer's pressure indicators.....	10
5.3.1	Specification of pressure indicators used for verification.....	10
5.3.2	Verification method of the sprayer pressure indicator.....	10
5.4	Flow meters for controlling the volume/area rate.....	10
5.4.1	General.....	10
5.4.2	Operating procedure No. 1: Verification by nozzle flow rate measurement.....	11
5.4.3	Operating Procedure No. 2: Verification by installing a calibrated flow meter in the circuit of the sprayer.....	11
5.5	System for controlling forward speed.....	12
5.6	Flow rate of the spray nozzles.....	12
5.6.1	General.....	12
5.6.2	Measurement with nozzles fitted on the sprayer.....	13
5.6.3	Measurement with nozzles removed from the sprayer.....	13
5.6.4	Measurement on spray gun / lance.....	13
5.7	Pressure drop.....	13
5.8	Pressure variation when the spray is switched off.....	13
5.9	Pressure distribution.....	13
	<b>Bibliography.....</b>	<b>15</b>