

# ISO 13332:2026-01 (E)

## Reciprocating internal combustion engines - Test code for the measurement of structure-borne noise emitted from high-speed and medium-speed reciprocating internal combustion engines measured at the engine feet

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		vi
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Measure environment .....</b>	<b>3</b>
4.1	Acoustic environment .....	3
4.2	Meteorological conditions .....	4
<b>5</b>	<b>Measuring instruments .....</b>	<b>4</b>
5.1	General rule .....	4
5.2	Verification .....	4
<b>6</b>	<b>Installation and operating conditions .....</b>	<b>4</b>
6.1	General rule .....	4
6.2	Installation conditions .....	4
6.3	Mounting Requirements .....	4
6.4	Operating conditions .....	5
<b>7</b>	<b>Acceleration measurement .....</b>	<b>5</b>
7.1	General rule .....	5
7.2	Uncertainty .....	5
7.3	Mount selection .....	6
7.4	Accelerometer Position .....	6
7.4.1	Recommended Position .....	6
7.4.2	Alternative arrangement .....	8
7.5	Accelerometer Installation .....	10
7.6	Preliminary Test .....	10
7.7	Formal Test .....	11
<b>8</b>	<b>Calculation .....</b>	<b>11</b>
8.1	Calculation of Velocity and Angular Velocity .....	11
8.2	Calculation of time-averaged velocity levels and time-averaged angular velocity levels in each measurement direction .....	12
<b>9</b>	<b>Recorded Information .....</b>	<b>12</b>
<b>10</b>	<b>Test Report .....</b>	<b>13</b>
<b>Annex A (normative) Other connections between the engine and test surroundings .....</b>		<b>14</b>
<b>Annex B (normative) Corrections if the accelerometers are not in the contact plane between the machinery foot and isolator .....</b>		<b>15</b>

<b>Annex C (normative) Determination of Frequency range of measurement .....</b>	<b>17</b>
<b>Annex D (normative) Test record .....</b>	<b>20</b>
<b>Bibliography .....</b>	<b>22</b>