

ISO 18623-1:2026-07 (E)

Air compressors and compressed air systems - Safety - Part 1: Air compressors

Contents

Page

Foreword	v
Introduction	vi
1 Scope	1
2 Normative references	1
3 Terms and definitions	3
3.1 General terms	3
3.2 Specific terms	4
4 Safety requirements and/or protective measures	4
4.1 General	4
4.2 Mechanical safety	5
4.2.1 Guards	5
4.2.2 Fluid injection	6
4.2.3 Loss of stability	6
4.2.4 Slip, trip and fall	6
4.3 Electrical safety	7
4.3.1 Generally applicable	7
4.3.2 Protection from overload	7
4.3.3 Protection from live parts	7
4.3.4 Portable and skid-mounted compressor units	7
4.4 Control systems	7
4.4.1 General	7
4.4.2 Failure of safety related control system energy supply	8
4.4.3 Start/restart	8
4.4.4 Manual suspension of safety functions	8
4.4.5 Emergency stop function	8
4.4.6 Safety-related stop function	8
4.4.7 Manual reset	9
4.4.8 External influences on electrical equipment	9
4.4.9 Electromagnetic phenomena	9
4.4.10 Pneumatic and/or hydraulic control systems	9
4.5 Thermal safety	10
4.6 Noise	10
4.7 Materials and substances processed, used or exhausted	10
4.7.1 Micro-organisms, biological and microbiological substances	10
4.7.2 Breathing difficulties	11
4.8 Fire and explosion	11
4.8.1 Electrostatic phenomena	11
4.8.2 Oil-flooded rotary air compressor units	11
4.8.3 Oil-lubricated reciprocating air compressor units	12
4.8.4 Oil-lubricated reciprocating compressor units operating above 5 000 kPa	12
4.8.5 Compressor units driven by combustion engines	12
4.9 Ergonomic principles	12
4.9.1 General	12
4.9.2 Manual handling of compressor units	13
4.9.3 Portable and skid-mounted compressor units	13
4.10 Failure of machinery parts and other functional disorders	13
4.10.1 Break-up during operation	13

4.10.2	Low temperature operation	14
4.10.3	Liquid shock	14
4.10.4	Coolant system	14
4.11	Pressure relief - fragmentation	15
4.11.1	General	15
4.11.2	Design specifications of pressure relief devices	15
4.11.3	Turbo compressor units	15
4.11.4	Multi-stage compressor units	15
4.12	Information and warning devices	16
5	Verification of safety requirements and/or protective measures	16
5.1	Pressure testing	16
5.2	Noise	16
5.2.1	General	16
5.2.2	Sound power level of compressor units for use outdoors	16
5.3	Stability of portable compressor units	16
5.4	Structure of verification	16
6	Information for use	18
6.1	General requirements	18
6.2	Accompanying documents (in particular instruction handbook)	19
6.2.1	Instruction handbook	19
6.2.2	Information relating to the use of the compressor/compressor unit	20
6.3	Specific types of compressors	21
6.3.1	General	21
6.3.2	Portable and skid-mounted air compressor units	21
6.3.3	Entry to inlet ducts and enclosures	22
6.4	Service instructions	22
6.4.1	General	22
6.4.2	Precautions for service/maintenance	23
6.5	Markings, signs and written warnings	23
6.5.1	Generally applicable	23
6.5.2	Compressor unit enclosures	23
6.5.3	Off-road portable and skid-mounted air compressor units	23
6.5.4	Markings (in particular data plate)	24
6.6	Noise	25
6.6.1	A-weighted emission sound pressure level and A-weighted sound power level declaration	25
6.6.2	Hearing protection	25
6.7	Dismantling	25
Annex A (informative)	List of significant hazards	26
Annex B (informative)	Control systems	28
Annex C (normative)	Labels, signs and tags	30
Bibliography		33