

ISO 10300-1:2001-08 (E)

Calculation of load capacity of bevel gears - Part 1: Introduction and general influence factors

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	Symbols and abbreviations	2
5	Application	10
6	External force and application factor, K_A	13
7	Dynamic factor, K_v	15
8	Face load factors, $K_{H>}$, $K_{F>}$	25
9	Transverse load factors, $K_{H=}$, $K_{F=}$	27
Annex A (normative) Calculation of bevel gear geometry		34
Annex B (informative) Values for application factor, K_A		45
Annex C (informative) Contact patterns		46