

# ISO 10300-3:2001-08 (E)

## Calculation of load capacity of bevel gears - Part 3: Calculation of tooth root strength

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	2
4	Symbols and abbreviated terms .....	2
5	Tooth breakage and safety factors .....	2
6	Gear-tooth rating formulae .....	3
7	Tooth form, $Y_{Fa}$ , and correction, $Y_{Sa}$ , factors -- Method B1 .....	5
8	Contact-ratio, $Y_e$ , bevel-gear, $Y_K$ , and load-sharing, $Y_{LS}$ , factors -- Method B1 .....	14
9	Bending-strength combined geometry factor, $Y_P$ -- Method B2 .....	15
10	Relative sensitivity factor for allowable stress number, $Y_{drelT}$ .....	21
11	Relative surface condition factor, $Y_{R\ rel\ T}$ .....	23
12	Size factor, $Y_X$ .....	25
13	Life factor, $Y_{NT}$ .....	26
Annex A (normative) Bevel gear adjustment factor, $Y_A$ -- Method B2 .....		29
Annex B (informative) Graphs of geometry factor, $Y_J$ -- Method B2 .....		31