

# ISO 6489-3:2004-06 (E)

## Agricultural vehicles - Mechanical connections between towed and towing vehicles - Part 3: Tractor drawbar

---

<b>Contents</b>		<b>Page</b>
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Specifications .....</b>	<b>2</b>
<b>4.1</b>	<b>Drawbar clevis .....</b>	<b>2</b>
<b>4.2</b>	<b>Drawbar hitch point .....</b>	<b>2</b>
<b>4.3</b>	<b>Drawbar categories .....</b>	<b>2</b>
<b>4.4</b>	<b>Drawbar location and position .....</b>	<b>3</b>
<b>4.5</b>	<b>Drawbar dimensions .....</b>	<b>4</b>
<b>5</b>	<b>Vertical drawbar load .....</b>	<b>5</b>
<b>6</b>	<b>PTO drive shaft clearance .....</b>	<b>5</b>
	<b>Bibliography .....</b>	<b>7</b>