

# DIN EN 12387:2006-04 (E)

## Footwear, leather and imitation leather goods manufacturing machines - Modular shoe repair equipment - Safety requirements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1	<b>Scope .....</b>	<b>5</b>
2	<b>Normative references .....</b>	<b>6</b>
3	<b>Terms and definitions .....</b>	<b>7</b>
4	<b>List of hazards .....</b>	<b>8</b>
5	<b>Safety requirements and/or measures .....</b>	<b>16</b>
6	<b>Verification of safety requirements and/or measures .....</b>	<b>20</b>
7	<b>Information for use .....</b>	<b>23</b>
<b>Annex A (normative) Requirements for covers and guards .....</b>		<b>26</b>
<b>Annex B (normative) Requirements for hold-to-run control device for combined heel and sole presses .....</b>		<b>27</b>
<b>Annex C (normative) Noise test code for modular shoe repair equipment .....</b>		<b>28</b>
<b>Annex D (normative) Requirements for dust extraction system .....</b>		<b>31</b>
<b>Annex E (normative) Minimum distances and working height for finishing machines .....</b>		<b>32</b>
<b>Annex F (normative) .....</b>		<b>33</b>
<b>Annex G (informative) Lighting for finishing machines .....</b>		<b>35</b>
<b>Bibliography .....</b>		<b>37</b>