

# DIN EN 14018:2006-01 (E)

## Agricultural and forestry machinery - Seed drills - Safety

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
1	Scope .....	5
2	Normative references .....	6
3	Terms and definitions .....	6
4	List of significant hazards .....	7
5	Safety requirements and/or protective measures .....	8
5.1	General .....	8
5.2	Controls .....	9
5.3	Swivelling and movable components .....	11
5.4	Hoppers .....	11
5.5	Loading .....	12
5.5.1	Safe access to loading location .....	12
5.5.2	Boarding means to loading location .....	14
5.6	Single seed drills .....	15
5.7	Blower .....	15
5.8	Flow rate calibration system .....	16
5.9	Hitching and clearance zone .....	16
5.10	Noise .....	18
5.10.1	Noise reduction as a safety requirement .....	18
5.10.2	Verification of requirements on noise based on noise emission values .....	18
6	Verification of the safety requirements and/or protective measures .....	18
	Swivelling and movable components .....	18
7	Information for use .....	18
7.1	Instruction handbook .....	18
7.2	Marking .....	20
	Annex A (informative) Examples of seed drills .....	21
	Annex B (informative) Stability of the tractor-seed drill combination .....	24
	Annex C (informative) Examples of pictograms .....	25
	Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/CE, amended by Directive 98/79/CE .....	26
	Bibliography .....	27