

DIN EN 14985:2007-08 (E)

Cranes - Slewing jib cranes

Contents		Page
Foreword		4
Introduction		5
1	Scope	6
2	Normative references	6
3	Terms and definitions	8
4	List of hazards	8
5	Safety requirements and/or protective measures	12
5.1	General	12
5.2	Requirements for strength and stability	12
5.2.1	Selection of classification parameters	12
5.2.2	Selection of loads and load combinations	12
5.2.3	Determination of factor 2	12
5.2.4	Stall load condition	13
5.2.5	Loads caused by acceleration	14
5.2.6	Jib side loading	14
5.2.7	Test loads	14
5.2.8	Conditions of use of permissible stress method and limit state method	14
5.2.9	Stability of rail mounted cranes	15
5.3	Electrotechnical equipment	16
5.3.1	Physical environment and operating conditions	16
5.3.2	Electrical supply	16
5.3.3	External protective earthing and equipotential bonding	16
5.3.4	Supply disconnecting and switching off	16
5.3.5	Protection against electric shock	17
5.3.6	Conductors and cables	17
5.3.7	Control circuits and control functions	17
5.3.8	Operator interface and mounted control devices	18
5.3.9	Electronic equipment	19
5.3.10	Control gear - location, mounting and enclosures	19
5.3.11	5.3.11 Electrical requirements for the installation of load handling devices	19
5.3.12	Electric motors	19
5.4	Non-electrotechnical equipment	19
5.4.1	General	19
5.4.2	Braking systems	20
5.4.3	Hoisting mechanism	21
5.4.4	Luffing system	21
5.4.5	Slew mechanism	22
5.4.6	Travel mechanism	23
5.4.7	Gear drives	23
5.5	Limiting and indicating devices	24
5.5.1	Rated capacity limiters	24
5.5.2	Indicators	25
5.5.3	Motion limiters	25
5.5.4	Performance limiters	25
5.6	Protection against special hazards	26
5.6.1	Hot surfaces	26

5.6.2	Radio equipment	26
5.6.3	Laser beams	26
5.6.4	Fire hazard	26
5.6.5	Exhaust gases	26
5.6.6	Fuelling	26
5.7	Man-machine interface	26
5.7.1	Controls and control stations	26
5.7.2	Guarding and access	27
5.7.3	Lighting	27
5.7.4	Reduction of noise by design	28
5.8	Equipment for information and warning	29
5.8.1	General	29
5.8.2	Location of visual display units	29
5.8.3	Safety colour	29
5.8.4	Warning lights	29
5.9	Personal protection equipment	30
6	Verification of the safety requirements and/or protective measures	30
6.1	General	30
6.2	Fitness for purpose testing	33
6.2.1	General	33
6.2.2	Tests	33
7	Information for use	35
7.1	Instructions for installation and safe use	35
7.2	Driver's manual	35
7.3	User's manual	36
7.4	Instructions for regular checks, inspections and tests	37
7.5	Instructions for maintenance	37
7.6	Markings	38
8	Information to be obtained from the purchaser	38
Annex A (informative) Guidance for classification according to EN 13001-1		39
Annex B (normative) Load combinations		47
Annex C (informative) Calculation of stall load factor for indirect acting lifting force limiter		48
Annex D (normative) Noise test code for slewing jib cranes		50
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC		56
Bibliography		57