

# DIN EN 12952-4:2011-10 (E)

## Water-tube boilers and auxiliary installations - Part 4: In-service boiler life expectancy calculations

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b> .....		<b>3</b>
<b>1</b>	<b>Scope</b> .....	<b>5</b>
<b>2</b>	<b>Normative references</b> .....	<b>5</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>5</b>
<b>4</b>	<b>Symbols and abbreviations</b> .....	<b>5</b>
<b>5</b>	<b>General</b> .....	<b>5</b>
<b>6</b>	<b>Calculations</b> .....	<b>5</b>
<b>Annex A (informative) Calculation of in-service creep damage</b> .....		<b>6</b>
<b>Annex B (informative) Calculation of in-service fatigue damage</b> .....		<b>10</b>
<b>Annex C (informative) Significant technical changes between this European Standard and the previous edition</b> .....		<b>20</b>
<b>Bibliography</b> .....		<b>21</b>