

# DIN ISO 11088:2018-10 (E)

## Alpine ski/binding/boot (S-B-B) system - Assembly, adjustment and inspection (ISO 11088:2018)

---

### Contents

	Page
<b>National foreword</b> .....	3
<b>National Annex NA (informative) Bibliography</b> .....	4
<b>Foreword</b> .....	5
<b>Introduction</b> .....	6
<b>1 Scope</b> .....	7
<b>2 Normative references</b> .....	7
<b>3 Terms and definitions</b> .....	7
<b>4 Principle</b> .....	9
<b>5 Skier's parameters</b> .....	9
5.1 General.....	9
5.2 Weight method.....	9
<b>6 Equipment parameters</b> .....	9
6.1 Choice of new equipment.....	9
6.2 Visual inspection and preparation of used equipment.....	9
6.3 Assembly.....	10
6.4 Binding-to-boot fitting adjustments.....	10
6.5 Initial indicator adjustment.....	10
6.6 Functional check (inspection of functions).....	10
6.7 Measurement of release moment.....	10
6.8 Report.....	11
<b>Annex A (normative) Definition of skier type</b> .....	12
<b>Annex B (normative) Method of setting</b> .....	14
<b>Annex C (normative) Flow chart</b> .....	16
<b>Annex D (normative) Clean versus lubricated diagnostic test for boot/binding compatibility</b> .....	18
<b>Annex E (informative) Drill</b> .....	19
<b>Bibliography</b> .....	20