DIN EN 17860-5:2025-06 (E)

Carrier cycles - Part 5: Electrical aspects

Contents

Page

European foreword 4

Introduction 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 7

4 General requirements 7
4.1 Risk assessment 7
4.2 Significant hazards and safety functions 7
4.2.1 Significant hazards 7
4.2.2 Safety function for control system of carrier EPAC 8
4.3 Prevention of unauthorized use 8

5 Electrical requirements 8
5.1 Electric system 8
5.2 Controls and symbols 8
5.3 Battery 9
5.4 External battery charger 9
5.5 Electric cables and couplers 9
5.5.1 General 9
5.5.2 Requirements 9
5.5.3 Test method 9
5.6 Wiring 9
5.7 Power cables and conduits 10
5.8 External and internal electrical connections 10
5.9 Moisture resistance 10
5.10 Mechanical strength test of the electrical components 10
5.10.1 General 10
5.10.2 Function related shock test 11
5.10.3 Impact related shock test - Lateral overturning 11
5.11 Maximum speed for which the electric motor gives assistance 11
5.11.1 Requirements 11
5.11.2 Test method 11
5.12 Walk and manoeuvring assistance mode 12
5.12.1 Requirements 12
5.12.2 Test method 12
5.13 Power management 13
5.13.1 Requirements 13
5.13.2 Test method - Auxiliary electric motor management 14
5.14 Measurement of the maximum continuous rated power 15
5.14.1 Requirements 15
5.14.2 Measurement 15
5.14.3 Alternative measurement 15
5.15 Electromagnetic compatibility 16
5.15.1 Emission 16
5.15.2 Immunity 16
5.15.3 Carrier EPAC in mains charging mode 16
5.16 Failure mode 17

5.16.1 Acoustical and / or visual warning 17
5.17 Anti-tampering measures 17
5.18 Thermal hazards 17
5.18.1 Non-continuous contact surface 17
5.18.2 Continuous contact surface 17
5.18.3 Ambient temperature 17
5.19 Recuperative braking 18
5.19.1 Braking 18
5.19.2 Brake light activation by recuperative braking 18
5.20 Electrical requirements for electric cargo trailers 18
5.20.1 Control for electric cargo trailers 18
5.20.2 Handcart mode for electric cargo trailers - Handcart mode speed test 18
5.20.3 Maximum speed test 18
5.20.4 Assistance power for electric cargo trailer 18
5.20.5 Activating the trailer mode 23
5.20.6 Plug connections for electric cargo trailers 23
5.20.7 Performance levels (PLrs) for control system of electric cargo trailers 24

Annex A (normative) Electromagnetic compatibility of carrier EPAC and ESA 26

Annex B (normative) Light, warning device, on/off symbols 27

Annex C (informative) Walk and manoeuvring assistance mode symbols 28

Annex D (informative) Measurement of the maximum continuous rated power -- Alternative measurement 29

Bibliography 31