

DIN EN 14595:2016-10 (E)

Tanks for transport of dangerous goods - Service equipment - Breather device

| Contents | | Page |
|---|---|-------------|
| European foreword..... | | 3 |
| Introduction..... | | 5 |
| 1 | Scope | 6 |
| 2 | Normative references..... | 6 |
| 3 | Terms and definitions..... | 6 |
| 4 | Functions | 6 |
| 5 | Design characteristics..... | 6 |
| 5.1 | General | 6 |
| 5.2 | Ingress protection | 7 |
| 5.3 | Pressure ratings..... | 7 |
| 5.3.1 | Above atmospheric relieving pressure (pressure relief)..... | 7 |
| 5.3.2 | Below atmospheric relieving pressure (vacuum) | 7 |
| 5.3.3 | Tank overturn..... | 7 |
| 5.4 | Flow capacity..... | 7 |
| 5.5 | Temperature range..... | 7 |
| 5.6 | Materials of construction..... | 7 |
| 5.7 | Dimensional characteristics..... | 7 |
| 5.8 | Electrical resistance..... | 7 |
| 6 | Tests | 7 |
| 6.1 | General | 7 |
| 6.2 | Production tests..... | 8 |
| 6.2.1 | General | 8 |
| 6.2.2 | Seat tightness test..... | 8 |
| 6.2.3 | Overturn seat tightness test..... | 9 |
| 6.3 | Type test..... | 9 |
| 6.3.1 | General | 9 |
| 6.3.2 | Seat tightness test..... | 9 |
| 6.3.3 | Overturn seat tightness test..... | 9 |
| 6.3.4 | Drop test..... | 10 |
| 6.3.5 | Test results..... | 11 |
| 7 | Marking | 11 |
| 8 | Installation, operating and maintenance instructions | 11 |
| Annex A (normative) Drop test apparatus | | 12 |
| Bibliography..... | | 13 |