

# ISO 5167-2:2003-03 (E)

## Measurement of fluid flow by means of pressure differential devices inserted in circular cross-section conduits running full - Part 2: Orifice plates

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions and symbols .....</b>	<b>1</b>
<b>4</b>	<b>Principles of the method of measurement and computation .....</b>	<b>2</b>
<b>5</b>	<b>Orifice plates .....</b>	<b>2</b>
<b>5.1</b>	<b>Description .....</b>	<b>2</b>
<b>5.2</b>	<b>Pressure tappings .....</b>	<b>6</b>
<b>5.3</b>	<b>Coefficients and corresponding uncertainties of orifice plates .....</b>	<b>10</b>
<b>5.4</b>	<b>Pressure loss, .....</b>	<b>13</b>
<b>6</b>	<b>Installation requirements .....</b>	<b>15</b>
<b>6.1</b>	<b>General .....</b>	<b>15</b>
<b>6.2</b>	<b>Minimum upstream and downstream straight lengths for installation between various fittings and the orifice plate .....</b>	<b>15</b>
<b>6.3</b>	<b>Flow conditioners .....</b>	<b>20</b>
<b>6.4</b>	<b>Circularity and cylindricality of the pipe .....</b>	<b>26</b>
<b>6.5</b>	<b>Location of orifice plate and carrier rings .....</b>	<b>27</b>
<b>6.6</b>	<b>Method of fixing and gaskets .....</b>	<b>28</b>
	<b>Annex A (informative) Tables of discharge coefficients and expansibility [expansion] factors .....</b>	<b>29</b>
	<b>Annex B (informative) Flow conditioners .....</b>	<b>41</b>
	<b>Bibliography .....</b>	<b>46</b>