

# ISO/TS 7024:2005-10 (E)

## Plastics piping systems for soil and waste discharge (low and high temperature) inside buildings - Thermoplastics - Recommended practice for installation

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and abbreviations .....</b>	<b>2</b>
3.1	General terms .....	2
3.2	Terms and definitions .....	2
3.3	Symbols .....	4
3.4	Abbreviations .....	6
<b>4</b>	<b>Design limits of the system .....</b>	<b>6</b>
<b>5</b>	<b>Storage, transport and handling .....</b>	<b>6</b>
5.1	General .....	6
5.2	Transport .....	6
5.3	Storage .....	7
5.4	Handling on site .....	9
<b>6</b>	<b>Installation .....</b>	<b>9</b>
6.1	General recommendations for installation .....	9
6.2	Recommendations for above-ground installation .....	11
6.3	Joining procedure .....	22
<b>7</b>	<b>Special precautions .....</b>	<b>29</b>
7.1	Concreting of thermoplastics systems within the building structure .....	29
7.2	Foaming of thermoplastics systems .....	34
7.3	Prevention of additional stresses in pipework .....	34
<b>8</b>	<b>Joining to other materials or other constructions .....</b>	<b>34</b>
8.1	General .....	34
8.2	Solvent-cement joints .....	34
8.3	Ring seal joints .....	34
8.4	Joining to non-thermoplastics components .....	35
8.5	Adaptors .....	36
<b>9</b>	<b>Environmental aspects .....</b>	<b>37</b>
<b>10</b>	<b>Fire resistance of pipework .....</b>	<b>37</b>
<b>11</b>	<b>Testing and inspection of installations .....</b>	<b>37</b>
11.1	Testing .....	37
11.2	General inspection .....	37
<b>12</b>	<b>Maintenance and cleaning of installations .....</b>	<b>38</b>
12.1	General .....	38
12.2	Cleaning and descaling techniques .....	38

<b>13</b>	<b>Chemical resistance of thermoplastics materials .....</b>	<b>38</b>
	<b>Annex A (informative) Recommendations for installation in buried conditions .....</b>	<b>39</b>
	<b>Bibliography .....</b>	<b>42</b>