

# ISO 3547-5:2007-10 (E)

## Plain bearings - Wrapped bushes - Part 5: Checking the outside diameter

---

| <b>Contents</b> |   | <b>Page</b> |
|-----------------|---|-------------|
|                 | <b>Foreword</b> .....   | <b>iv</b>   |
| <b>1</b>        | <b>Scope</b> .....  | <b>1</b>    |
| <b>2</b>        | <b>Normative references</b> .....                                 | <b>1</b>    |
| <b>3</b>        | <b>Symbols and units</b> .....                                    | <b>2</b>    |
| <b>4</b>        | <b>Outside diameter, Do</b> .....                                 | <b>2</b>    |
| <b>5</b>        | <b>Purpose of checking</b> .....                                  | <b>3</b>    |
| <b>6</b>        | <b>Methods of checking</b> .....                                  | <b>3</b>    |
| <b>7</b>        | <b>Selection of checking method for outside diameter</b> .....    | <b>3</b>    |
| <b>11</b>       | <b>Specifications on drawings of bushes</b> .....                 | <b>14</b>   |
| <b>12</b>       | <b>Specifications for control of the checking equipment</b> ..... | <b>14</b>   |
|                 | <b>Bibliography</b> .....   | <b>15</b>   |