# DIN EN 16631:2015-07 (E)

## LPG equipment and accessories - Pressure relief valves for LPG pressure vessels - Reconditioning requirements

## Contents

Page


Foreword ..... 3

Introduction ..... 4

1 Scope ..... 5

2 Normative references ..... 5

3 Terms and definitions ..... 5

4 General ..... 6

5 Materials ..... 6
5.1 General ..... 6
5.2 Lubricants, sealants and adhesives ..... 6
5.3 Shelf life ..... 6
5.3.1 Shelf life of components ..... 6
5.3.2 Storage life of assembled PRVs ..... 7

6 Inspection ..... 7

7 Reconditioning ..... 7

8 Pressure setting ..... 8
8.1 General ..... 8
8.2 Setting and testing of PRVs ..... 8

9 Changing the set pressure ..... 9

10 Marking ..... 9

11 Documentation/Certification ..... 9

12 Operating instructions ..... 9

Annex A (informative) Assessment of PRVs by sampling ..... 11

A.1 General testing of PRVs on a sampling basis ..... 11
A.2 Sample size ..... 11
A.3 Sample selection ..... 11
A.4 Inspection period ..... 12
A.5 Pass criteria ..... 12

Bibliography ..... 13