

# DIN EN 16631:2025-03 (E)

## LPG equipment and accessories - Pressure relief valves for LPG pressure vessels - Reconditioning requirements

---

| <b>Contents</b>  |  | <b>Page</b> |
|--|--|-------------|
| European foreword .....                                  |  | 3           |
| Introduction .....                                       |  | 4           |
| 1  | Scope .....                                | 5           |
| 2  | Normative references .....                 | 5           |
| 3  | Terms and definitions .....                | 5           |
| 4  | General .....                              | 6           |
| 5  | Materials .....                            | 7           |
| 5.1  | General .....                              | 7           |
| 5.2  | Lubricants, sealants and adhesives .....   | 7           |
| 5.3  | Shelf life .....                           | 7           |
| 5.3.1  | Shelf life of unassembled components ..... | 7           |
| 5.3.2  | Storage life of assembled PRVs .....       | 7           |
| 6  | Inspection .....                           | 7           |
| 7  | Reconditioning .....                       | 8           |
| 8  | Pressure setting .....                     | 8           |
| 8.1  | General .....                              | 8           |
| 8.2  | Setting and testing of PRVs .....          | 9           |
| 9  | Changing the set pressure .....            | 9           |
| 10   | Marking .....                              | 10          |
| 11   | Reconditioning records .....               | 10          |
| 12   | Operating instructions .....               | 10          |
| Annex A (normative) Assessment of PRVs by sampling ..... |  | 11          |
| Bibliography .....                                       |  | 13          |