DIN EN 13856:2026-08 (E)

LPG equipment and accessories - Minimum requirements for the content of the user manual for automotive LPG systems

Contents

Page

European foreword 3

Introduction 4

1 Scope 5

2 Normative references 5

3 Terms and definitions 5

4 General 5

5 of the user manual 5
5.1 LPG system description 5
5.2 Safety instructions 6
5.3 Operation of the LPG system 6
5.3.1 Filling of the LPG container 6
5.3.2 Switch-over procedure 6
5.3.3 Opening / closing of manual valves when fitted 6
5.3.4 Level indicator 6
5.4 Maintenance 6
5.5 Defects and repair 6

Bibliography 7