

# DIN EN 14570:2006-04 (E)

## Equipping of LPG tanks overground and underground

---

<b>Contents</b>		<b>Page</b>
<b>1</b>	<b>Scope .....</b>	<b>4</b>
<b>2</b>	<b>Normative references .....</b>	<b>4</b>
<b>3</b>	<b>Terms, definitions and abbreviations .....</b>	<b>4</b>
<b>4</b>	<b>Tank equipment .....</b>	<b>6</b>
<b>5</b>	<b>Operational functions .....</b>	<b>7</b>
<b>6</b>	<b>Equipping .....</b>	<b>11</b>
<b>7</b>	<b>Checking and testing .....</b>	<b>12</b>
<b>8</b>	<b>Storage, handling and transportation .....</b>	<b>12</b>
<b>9</b>	<b>Documentation .....</b>	<b>12</b>
<b>Annex A (informative) Example of alternative means of over pressure protection for underground/mounded tanks .....</b>		<b>14</b>
<b>Annex B (normative) Settings and discharge rates for pressure relief valves .....</b>		<b>15</b>
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 97/23/EC .....</b>		<b>17</b>
<b>Bibliography .....</b>		<b>18</b>