

# ISO 4000-1:2013-02 (E)

## Passenger car tyres and rims - Part 1: Tyres (metric series)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Designation .....</b>	<b>1</b>
<b>4.1</b>	<b>Size and construction .....</b>	<b>1</b>
<b>4.2</b>	<b>Service description .....</b>	<b>3</b>
<b>4.3</b>	<b>Other service characteristics .....</b>	<b>4</b>
<b>5</b>	<b>Marking .....</b>	<b>6</b>
<b>6</b>	<b>Tyre dimensions .....</b>	<b>7</b>
<b>6.1</b>	<b>Rounding values .....</b>	<b>7</b>
<b>6.2</b>	<b>Calculation of design tyre dimensions .....</b>	<b>7</b>
<b>6.3</b>	<b>Calculation of maximum overall (grown) tyre dimensions in service tyres mounted on their measuring rims .....</b>	<b>8</b>
<b>6.4</b>	<b>Calculation of minimum tyre dimensions for radial-ply tyres mounted on their measuring rims .....</b>	<b>9</b>
<b>6.5</b>	<b>Range of approved rims .....</b>	<b>9</b>
<b>7</b>	<b>Tyre dimension measurement procedure .....</b>	<b>10</b>
<b>8</b>	<b>Inflation pressures .....</b>	<b>10</b>
<b>9</b>	<b>Load capacities .....</b>	<b>11</b>
<b>10</b>	<b>Choice of tyre sizes .....</b>	<b>11</b>
<b>11</b>	<b>Camber angle .....</b>	<b>12</b>
<b>Annex A (normative) Guideline values for metric-series tyres .....</b>		<b>14</b>
<b>Annex B (normative) Load indices for passenger car tyres .....</b>		<b>23</b>
<b>Annex C (normative) Minimum inflation pressure for intermediate load .....</b>		<b>45</b>
<b>Annex D (informative) Other existing size markings .....</b>		<b>53</b>
<b>Bibliography .....</b>		<b>55</b>