

# ISO/TS 22762-4:2014-07 (E)

## Elastomeric seismic-protection isolators - Part 4: Guidance on the application of ISO 22762-3

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
1	<b>Scope .....</b>	<b>1</b>
2	<b>Normative references .....</b>	<b>1</b>
3	<b>Terms and definitions .....</b>	<b>1</b>
4	<b>Guidance on the use of Clause 4 of ISO 22762-3 .....</b>	<b>1</b>
5	<b>Guidance on the use of Clause 5 of ISO 22762-3 .....</b>	<b>1</b>
6	<b>Guidance on the use of Clause 6 of ISO 22762-3 .....</b>	<b>1</b>
6.1	<b>General .....</b>	<b>1</b>
6.2	<b>Type tests and routine tests .....</b>	<b>1</b>
6.3	<b>Functional requirements .....</b>	<b>3</b>
6.4	<b>Design compressive force and design shear displacement .....</b>	<b>3</b>
6.5	<b>Performance requirements .....</b>	<b>4</b>
7	<b>Guidance on the use of Clause 7 of ISO 22762-3 .....</b>	<b>24</b>
7.1	<b>General .....</b>	<b>24</b>
7.2	<b>Compressive stiffness .....</b>	<b>24</b>
8	<b>Guidance on the use of Clause 8 of ISO 22762-3 .....</b>	<b>31</b>
9	<b>Guidance on the use of Clause 9 of ISO 22762-3 .....</b>	<b>31</b>
10	<b>Guidance on the use of Clause 10 of ISO 22762-3 .....</b>	<b>31</b>
11	<b>Guidance on the use of Clause 11 of ISO 22762-3 .....</b>	<b>31</b>