

# ISO 14960-1:2023-11 (E)

## Tubeless tyres - Valves and components - Part 1: Snap-in tyre valves test methods

---

### Contents

	Page
<b>Foreword .....</b>	<b>iv</b>
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms and definitions .....</b>	<b>1</b>
<b>4 Methods for testing tubeless tyres snap-in valves .....</b>	<b>2</b>
<b>4.1 General .....</b>	<b>2</b>
<b>4.2 Ageing .....</b>	<b>2</b>
<b>4.3 Test fixtures .....</b>	<b>2</b>
<b>4.4 Installation .....</b>	<b>2</b>
<b>5 Test methods and performances requirements .....</b>	<b>3</b>
<b>5.1 Adhesion .....</b>	<b>3</b>
<b>5.1.1 Test method .....</b>	<b>3</b>
<b>5.1.2 Performances .....</b>	<b>3</b>
<b>5.2 Valve core seal .....</b>	<b>3</b>
<b>5.2.1 Room temperature test .....</b>	<b>3</b>
<b>5.2.2 Low temperature test .....</b>	<b>4</b>
<b>5.2.3 High temperature test .....</b>	<b>4</b>
<b>5.3 Valve cap seal (optional, for sealing caps only) .....</b>	<b>4</b>
<b>5.3.1 Test method .....</b>	<b>4</b>
<b>5.3.2 Performances .....</b>	<b>4</b>
<b>5.4 Valve to rim seal .....</b>	<b>5</b>
<b>5.4.1 Low temperature .....</b>	<b>5</b>
<b>5.4.2 High temperature .....</b>	<b>6</b>
<b>5.5 Installation tests .....</b>	<b>7</b>
<b>5.5.1 Force to seat .....</b>	<b>7</b>
<b>5.5.2 Force to pull out .....</b>	<b>7</b>
<b>5.6 Burst .....</b>	<b>8</b>
<b>5.6.1 Test method .....</b>	<b>8</b>
<b>5.6.2 Performances .....</b>	<b>8</b>
<b>5.7 Ozone resistance .....</b>	<b>8</b>
<b>5.7.1 Test methods .....</b>	<b>8</b>
<b>5.7.2 Performances .....</b>	<b>8</b>
<b>5.8 Flexing resistance .....</b>	<b>8</b>
<b>5.8.1 Test methods .....</b>	<b>8</b>
<b>5.8.2 Performances .....</b>	<b>9</b>
<b>5.9 Resistance tests .....</b>	<b>9</b>
<b>5.9.1 Valve core torque resistance .....</b>	<b>9</b>
<b>5.9.2 Valve core cycling test .....</b>	<b>10</b>
<b>5.9.3 Valve nose resistance test .....</b>	<b>10</b>