

# ISO 21015:2007-06 (E)

## Office furniture - Office work chairs - Test methods for the determination of stability, strength and durability

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>General test conditions .....</b>	<b>2</b>
4.1	Preliminary preparation .....	2
4.2	Test equipment .....	3
4.3	Application of forces .....	3
4.4	Tolerances .....	3
4.5	Sequence of testing .....	3
4.6	Inspection and assessment of results .....	3
<b>5</b>	<b>Test apparatus .....</b>	<b>5</b>
5.1	Test surface .....	5
5.2	Stops .....	5
5.3	Seat-loading pad .....	5
5.4	Smaller seat-loading pad .....	6
5.5	Local loading pad .....	6
5.6	Back-loading pad .....	6
5.7	Arm-rest durability test apparatus .....	7
5.8	Strap .....	8
5.9	Stability-loading device .....	9
5.10	Loading discs .....	9
5.11	Test surface for castor durability .....	9
<b>6</b>	<b>Loading points .....</b>	<b>9</b>
6.1	Loading point A .....	9
6.2	Loading point B .....	9
6.3	Loading point C .....	9
6.4	Loading point D .....	10
6.5	Loading point E .....	10
6.6	Loading point F .....	10
6.7	Loading point G .....	10
6.8	Loading point H .....	10
6.9	Loading point J .....	10
<b>7</b>	<b>Test methods .....</b>	<b>11</b>
7.1	Stability .....	11
7.2	Static-load tests .....	15
7.3	Durability tests .....	17
<b>8</b>	<b>Test report .....</b>	<b>19</b>
<b>Annex A (informative)</b>	<b>Guidance for the choice of forces, cycles, etc., for stability, strength and durability tests -- General principles .....</b>	<b>20</b>
<b>Annex B (normative)</b>	<b>Seat-loading pad data .....</b>	<b>23</b>
<b>Annex C (normative)</b>	<b>Stability-loading device data .....</b>	<b>26</b>