

# DIN EN 1022:2024-04 (E)

## Furniture - Seating - Determination of stability

---

<b>Contents</b>		<b>Page</b>
European foreword .....		3
1	Scope .....	4
2	Normative references .....	4
3	Terms and definitions .....	4
4	General test conditions .....	7
4.1	General .....	7
4.2	Application of forces .....	7
4.3	Tolerances .....	8
5	Test equipment .....	8
5.1	General .....	8
5.2	Loading point template .....	8
5.3	Floor .....	12
5.4	Stops .....	12
5.5	Stability loading pad .....	12
5.6	Stability loading device .....	14
5.7	Loading discs .....	15
5.8	Support apparatus .....	15
5.9	Support for tests for reclining back rests .....	16
5.10	Local loading pad .....	16
5.11	Seat loading pad .....	16
6	Determination of seat and back loading points .....	17
6.1	Single column seats .....	17
6.2	All other seating .....	18
6.3	Loungers .....	20
6.4	Determination of height of seat loading point .....	20
7	Test methods for assessing stability of all seating except loungers .....	20
7.1	General .....	20
7.2	Requirements .....	23
7.3	Test procedures, all seating .....	23
7.4	Additional test procedures for seating with reclining back rests .....	33
8	Loungers .....	40
8.1	General .....	40
8.2	Requirements .....	42
8.3	Test procedures .....	42
9	Test report .....	43
Annex A (normative) Seat loading pad data .....		44
Annex B (normative) Test parameters .....		47
Annex C (informative) Semi-circular section loading point template .....		49