

DIN EN 1022:2024-04 (E)

Furniture - Seating - Determination of stability

Contents		Page
European foreword		3
1	Scope	4
2	Normative references	4
3	Terms and definitions	4
4	General test conditions	7
4.1	General	7
4.2	Application of forces	7
4.3	Tolerances	8
5	Test equipment	8
5.1	General	8
5.2	Loading point template	8
5.3	Floor	12
5.4	Stops	12
5.5	Stability loading pad	12
5.6	Stability loading device	14
5.7	Loading discs	15
5.8	Support apparatus	15
5.9	Support for tests for reclining back rests	16
5.10	Local loading pad	16
5.11	Seat loading pad	16
6	Determination of seat and back loading points	17
6.1	Single column seats	17
6.2	All other seating	18
6.3	Loungers	20
6.4	Determination of height of seat loading point	20
7	Test methods for assessing stability of all seating except loungers	20
7.1	General	20
7.2	Requirements	23
7.3	Test procedures, all seating	23
7.4	Additional test procedures for seating with reclining back rests	33
8	Loungers	40
8.1	General	40
8.2	Requirements	42
8.3	Test procedures	42
9	Test report	43
Annex A (normative) Seat loading pad data		44
Annex B (normative) Test parameters		47
Annex C (informative) Semi-circular section loading point template		49