

# DIN EN 15316-4-2:2008-09 (E)

## Heating systems in buildings - Method for calculation of system energy requirements and system efficiencies - Part 4-2: Space heating generation systems, heat pump systems

---

<b>Contents</b>		<b>Page</b>
Foreword .....		4
Introduction .....		6
<b>1</b>	<b>Scope .....</b>	<b>6</b>
<b>2</b>	<b>Normative references .....</b>	<b>7</b>
<b>3</b>	<b>Terms, definitions, symbols and units .....</b>	<b>8</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>8</b>
<b>3.2</b>	<b>Symbols and units .....</b>	<b>13</b>
<b>4</b>	<b>Principle of the method .....</b>	<b>15</b>
<b>4.1</b>	<b>Heat balance of generation subsystem .....</b>	<b>15</b>
<b>4.2</b>	<b>Energy input needed to meet the heat requirements .....</b>	<b>18</b>
<b>4.3</b>	<b>Auxiliary energy WHW,gen,aux .....</b>	<b>19</b>
<b>4.4</b>	<b>Recoverable, recovered and unrecoverable heat losses .....</b>	<b>19</b>
<b>4.5</b>	<b>Calculation periods .....</b>	<b>19</b>
<b>4.6</b>	<b>Calculation by zones .....</b>	<b>19</b>
<b>4.7</b>	<b>Heat pumps with combined space heating and domestic hot water production .....</b>	<b>20</b>
<b>5</b>	<b>Generation subsystem calculation .....</b>	<b>22</b>
<b>5.1</b>	<b>General .....</b>	<b>22</b>
<b>5.2</b>	<b>Simplified seasonal performance method based on system typology (system typology method) .....</b>	<b>22</b>
<b>5.2.1</b>	<b>Principle of the system typology method .....</b>	<b>22</b>
<b>5.2.2</b>	<b>Calculation procedure of the system typology method .....</b>	<b>23</b>
<b>5.3</b>	<b>Detailed case specific seasonal performance method based on component efficiency (bin-method) .....</b>	<b>24</b>
<b>5.3.1</b>	<b>Principle of the bin method .....</b>	<b>24</b>
<b>5.3.2</b>	<b>Input data for the calculation with the bin method .....</b>	<b>28</b>
<b>5.3.3</b>	<b>Calculation steps to be performed in the bin method .....</b>	<b>29</b>
<b>5.3.4</b>	<b>Heat energy requirements for space heating and domestic hot water mode for the bins ...</b>	<b>33</b>
<b>5.3.5</b>	<b>Heating capacity and COP at full load .....</b>	<b>34</b>
<b>5.3.6</b>	<b>COP at part load operation .....</b>	<b>38</b>
<b>5.3.7</b>	<b>Thermal losses through the generator envelope .....</b>	<b>39</b>
<b>5.3.8</b>	<b>Calculation of back-up heater .....</b>	<b>40</b>
<b>5.3.9</b>	<b>Running time of the heat pump .....</b>	<b>48</b>
<b>5.3.10</b>	<b>Auxiliary energy .....</b>	<b>55</b>
<b>5.3.11</b>	<b>Total thermal losses and recoverable thermal loss of the generation subsystem .....</b>	<b>56</b>
<b>5.3.12</b>	<b>Calculation of total energy input .....</b>	<b>58</b>
<b>5.3.13</b>	<b>Summary of output values .....</b>	<b>63</b>
<b>Annex A (informative)</b>	<b>Example of evaluation of meteorological data .....</b>	<b>64</b>
<b>Annex B (informative)</b>	<b>Default values of parameters for the case specific seasonal performance method .....</b>	<b>69</b>
<b>B.1</b>	<b>Controller setting of flow temperature (heating characteristic curve) .....</b>	<b>69</b>

B.2	Temperature correction factor for domestic hot water storage loading .....	70
B.3	Average water temperature of domestic hot water storages .....	70
B.4	Generator envelope .....	70
B.5	Generation subsystem auxiliaries .....	71
B.6	Factor fcombi for simultaneous operation .....	71
B.7	Temperature reduction factor linked to location .....	71
B.8	Efficiency value of the electrical back-up heater for space heating or DHW operation .....	72
<b>Annex C (informative) Calculation method for source and sink temperature correction with fixed exergetic efficiency .....</b>		<b>73</b>
<b>Annex D (informative) Calculation example .....</b>		<b>77</b>
D.1	Detailed calculation example .....	77
D.1.1	System configuration .....	77
D.1.2	Input data for the calculation (according to 5.3.2) .....	77
D.1.3	Calculation .....	80
D.2	Calculation example (spreadsheet format) .....	99
D.2.1	System configuration .....	99
D.2.2	Input data for the calculation (according to 5.3.2) .....	99
D.2.3	Calculation .....	100
<b>Annex E (informative) Example for tabulated values of the system typology method as national annex for the Netherlands .....</b>		<b>104</b>
E.1	General .....	104
E.2	Scope .....	104
E.3	References .....	104
E.4	Heat pump seasonal performance .....	104
E.4.1	Residential buildings .....	104
E.4.2	Non-residential buildings .....	105
E.5	Heat pump installation efficiency .....	106
E.6	Heat pump installation energy consumption .....	108
E.7	Heat pump installation auxiliary energy consumption .....	108
<b>Annex F (informative) Example values for parameters to accomplish the case specific heat pump calculation method (bin method) .....</b>		<b>109</b>
F.1	General .....	109
F.2	Temperatures .....	109
F.2.1	Source temperatures .....	109
F.3	Example values for heating capacity and coefficient of performance for electrically driven heat pumps .....	111
F.3.1	General .....	111
F.3.2	Heating capacity .....	111
F.3.3	COP .....	114
F.4	Gas engine-driven heat pumps .....	116
F.4.1	Preface .....	116
F.4.2	Heating capacity .....	117
F.4.3	COP .....	119
F.5	Absorption heat pumps .....	121
F.5.1	General .....	121
F.5.2	NH3/H2O heat pumps - outside air-to-water .....	122
F.5.3	NH3/H2O heat pumps - brine-to-water .....	123
F.5.4	NH3/H2O heat pumps - water-to-water .....	124
F.5.5	H2O/LiBr double effect heat pumps .....	125
F.6	Heat pumps with domestic hot water production (DHW) - Heating capacity of domestic hot water heat pumps .....	126
<b>Bibliography .....</b>		<b>127</b>