

# DIN EN 15316-4-8:2011-05 (E)

## Heating systems in buildings - Method for calculation of system energy requirements and system efficiencies - Part 4-8: Space heating generation systems, air heating and overhead radiant heating systems

---

| <b>Contents</b>              |  | <b>Page</b> |
|------------------------------|--|-------------|
| Foreword .....               |  | 3           |
| Introduction .....           |  | 4           |
| <b>1</b>                     | <b>Scope .....</b>   | <b>5</b>    |
| <b>2</b>                     | <b>Normative references .....</b>  | <b>5</b>    |
| <b>3</b>                     | <b>Terms, definitions, symbols and units .....</b>   | <b>6</b>    |
| <b>3.1</b>                   | <b>Terms and definitions .....</b>   | <b>6</b>    |
| <b>3.2</b>                   | <b>Symbols and units .....</b>   | <b>9</b>    |
| <b>4</b>                     | <b>Principle of the method .....</b>   | <b>11</b>   |
| <b>4.1</b>                   | <b>Heat balance of the generation sub-system, including control of heat generation .....</b> | <b>11</b>   |
| <b>4.1.1</b>                 | <b>Physical factors taken into account .....</b>   | <b>11</b>   |
| <b>4.1.2</b>                 | <b>Calculation structure (input and output data) .....</b>                                   | <b>12</b>   |
| <b>4.2</b>                   | <b>Thermal energy required for heat generation .....</b>                                     | <b>14</b>   |
| <b>4.3</b>                   | <b>Auxiliary energy <math>W_{gen}</math> .....</b>   | <b>14</b>   |
| <b>4.4</b>                   | <b>Recoverable, recovered and unrecoverable heat loss .....</b>                              | <b>14</b>   |
| <b>4.5</b>                   | <b>Calculation steps .....</b>   | <b>15</b>   |
| <b>5</b>                     | <b>Generation system calculation .....</b>   | <b>15</b>   |
| <b>5.1</b>                   | <b>Principle of the method .....</b>   | <b>15</b>   |
| <b>5.2</b>                   | <b>Load factor .....</b>   | <b>17</b>   |
| <b>5.3</b>                   | <b>Specific heat losses .....</b>  | <b>18</b>   |
| <b>5.3.1</b>                 | <b>General .....</b>   | <b>18</b>   |
| <b>5.3.2</b>                 | <b>Heat losses through the chimney with burner on (ch,on) .....</b>                          | <b>18</b>   |
| <b>5.3.3</b>                 | <b>Induced ventilation heat losses (vent) .....</b>  | <b>19</b>   |
| <b>5.3.4</b>                 | <b>Losses through the generator envelope (gen,env) .....</b>                                 | <b>19</b>   |
| <b>5.3.5</b>                 | <b>Pilot flame losses (plt) .....</b>  | <b>20</b>   |
| <b>5.3.6</b>                 | <b>Heat recovery from condensation (cond) .....</b>  | <b>20</b>   |
| <b>5.4</b>                   | <b>Total heat losses .....</b>   | <b>20</b>   |
| <b>5.4.1</b>                 | <b>Burner ON losses (on) .....</b>   | <b>20</b>   |
| <b>5.4.2</b>                 | <b>Burner OFF Losses (off) .....</b>   | <b>20</b>   |
| <b>5.5</b>                   | <b>Auxiliary energy .....</b>  | <b>21</b>   |
| <b>5.5.1</b>                 | <b>Auxiliary energy related to time burner on .....</b>                                      | <b>21</b>   |
| <b>5.5.2</b>                 | <b>Auxiliary energy of additional devices (after the burner) .....</b>                       | <b>21</b>   |
| <b>5.6</b>                   | <b>Calculation procedure .....</b>   | <b>22</b>   |
| <b>5.6.1</b>                 | <b>Calculation procedure for on-off generators .....</b>                                     | <b>22</b>   |
| <b>5.6.2</b>                 | <b>Calculation procedure for modulating or multistage generators .....</b>                   | <b>22</b>   |
| <b>Annex A (informative)</b> | <b>Default values .....</b>  | <b>26</b>   |
| <b>A.1</b>                   | <b>Default values for (ch,on) .....</b>  | <b>26</b>   |
| <b>A.2</b>                   | <b>Default values for (vent) .....</b>   | <b>27</b>   |
| <b>A.3</b>                   | <b>Default values for (gen,env) .....</b>  | <b>28</b>   |
| <b>A.4</b>                   | <b>Default values for (plt) .....</b>  | <b>29</b>   |
| <b>A.5</b>                   | <b>Default values for (cond) .....</b>   | <b>29</b>   |
| <b>A.6</b>                   | <b>Default values for auxiliary energy .....</b>   | <b>30</b>   |

|  |           |
|--|-----------|
| <b>Annex B (informative) Examples of use of the calculation .....</b>              | <b>31</b> |
| <b>B.1 Calculation example 1 - Overhead radiant tube heating system .....</b>      | <b>31</b> |
| <b>B.2 Calculation example 2 -- Overhead luminous radiant heating system .....</b> | <b>33</b> |
| <b>B.3 Calculation example 3 -- Condensing air heating system .....</b>            | <b>34</b> |
| <b>Bibliography .....</b>  | <b>37</b> |