DIN EN 15241:2011-06 (E)

Ventilation for buildings - Calculation methods for energy losses due to ventilation and infiltration in buildings (inclu des Corrigendum AC:2011)

Contents

Page

Foreword 3

1 Scope 6

2 Normative references 6

3 Terms and definitions 6

4 Symbols and abbreviations 7

5 General approach 8

6 Steady state calculation 9
6.1 Basis of the calculation method 9
6.2 Air entering through infiltration, passive air inlets or windows 9
6.3 Air entering through balanced or supply only system calculation 9
6.3.1 General 9
6.3.2 Duct heat losses 10
6.3.3 Duct flow losses 10
6.3.4 Fan 10
6.3.5 heat exchanger 13
6.3.6 Mixing boxes 15
6.3.7 Pre-heating 16
6.3.8 Pre-cooling 16
6.3.9 Humidifying in winter 17
6.3.10 Dehumidification 17

7 Implementation of the method 18
7.1 General 18
7.2 Hourly method 18
7.3 Monthly methods 19
7.3.1 System with no or low humidity impact 19
7.3.2 System with medium or high humidity impact 19
7.4 Statistical approach to be applied at national level 20

Annex A (informative) A simplified model of a Ground to Air Heat Exchanger 21

A.1 Background and summary 21
A.2 Overview of program links, variables, parameters and constants 22
A.3 Physical description of the ground to air heat x-change model 23

Bibliography 26