

DIN EN 15241:2011-06 (E)

Ventilation for buildings - Calculation methods for energy losses due to ventilation and infiltration in buildings (includ es Corrigendum AC:2011)

Contents		Page
Foreword		3
1	Scope	6
2	Normative references	6
3	Terms and definitions	6
4	Symbols and abbreviations	7
5	General approach	8
6	Steady state calculation	9
6.1	Basis of the calculation method	9
6.2	Air entering through infiltration, passive air inlets or windows	9
6.3	Air entering through balanced or supply only system calculation	9
6.3.1	General	9
6.3.2	Duct heat losses	10
6.3.3	Duct flow losses	10
6.3.4	Fan	10
6.3.5	heat exchanger	13
6.3.6	Mixing boxes	15
6.3.7	Pre-heating	16
6.3.8	Pre-cooling	16
6.3.9	Humidifying in winter	17
6.3.10	Dehumidification	17
7	Implementation of the method	18
7.1	General	18
7.2	Hourly method	18
7.3	Monthly methods	19
7.3.1	System with no or low humidity impact	19
7.3.2	System with medium or high humidity impact	19
7.4	Statistical approach to be applied at national level	20
Annex A (informative)	A simplified model of a Ground to Air Heat Exchanger	21
A.1	Background and summary	21
A.2	Overview of program links, variables, parameters and constants	22
A.3	Physical description of the ground to air heat x-change model	23
Bibliography		26