

# DIN EN 16798-7:2017-11 (En glisch)

**Energy performance of buildings - Ventilation for buildings - Part 7: Calculation methods for the determination of air flow rates in buildings including infiltration (Modules M5-5)**

---

## Contents

	Page
European foreword .....	6
Introduction .....	9
1 Scope .....	11
Table 1 -- Position of this standard (in casu M5-1, M5-5, M5-6, M5-8) within the modular structure of the set of EPB standards .....	12
2 Normative references .....	13
3 Terms and definitions .....	14
4 Symbols and subscripts .....	15
4.1 Symbols .....	15
Table 2 -- Symbols and units .....	15
4.2 Subscripts .....	17
Table 3 -- Subscripts .....	17
5 Brief description of the methods .....	18
5.1 Output of the methods .....	18
5.2 General description of the methods .....	18
5.3 Selection criteria between the methods .....	19
6 Calculation method, method 1 -- Determination of air flow rates based on detailed building characteristics .....	19
6.1 Output data .....	19
Table 4 -- Output data of method 1 .....	19
6.2 Calculation intervals .....	20
6.3 Input data .....	20
6.3.1 General .....	20
6.3.2 Product data .....	21
Table 5 -- Product technical input data list .....	21
6.3.3 System design data .....	22
Table 6 -- Identifiers for VENT_SYS_OP .....	22
Table 7 -- Process design input data list .....	22
Table 8 -- Identifiers for SUP_AIR_TEMP_CTRL .....	24
Table 9 -- Identifiers for SUP_AIR_FLW_CTRL .....	24
6.3.4 Operating conditions .....	24
Table 10 -- Operating conditions data list .....	24

6.3.5	Constants and physical data .....	26
<b>Table 11 -- Constants and physical data .....</b>		<b>26</b>
6.3.6	Input data from Annex A (Annex B) .....	26
6.4	Calculation procedure, method 1 .....	26
6.4.1	Applicable time intervals and states of operation .....	26
6.4.2	Operating conditions calculation .....	26
6.4.3	Calculation of air flow rates .....	28
7	Method 2 -- Determination of air flow rates based on statistical approach .....	38
7.1	Output data .....	38
<b>Table 12 -- Output data of method 2 .....</b>		<b>39</b>
7.2	Calculation intervals .....	39
7.3	Input data .....	39
7.4	Calculation procedure, method 2 .....	39
7.4.1	General .....	39
7.4.2	Description of the statistically based simplified method .....	40
7.4.3	Justification of the method .....	40
8	Quality control .....	40
9	Compliance check .....	41
<b>Annex A (normative) Input and method selection data sheet - Template .....</b>		<b>42</b>
A.1	General .....	42
A.2	References .....	43
<b>Table A.1 --References .....</b>		<b>43</b>
A.3	Input data method 1 .....	43
A.3.1	Product description data .....	43
A.3.2	Product technical data .....	43
A.3.2.1	Discharge coefficient for vents, air terminal devices, windows .....	43
A.3.2.2	Airflow exponent for vents, air terminal devices, windows .....	43
A.3.2.3	Combustion air flows factors .....	44
<b>Table A.2 -- Data for appliance system factor .....</b>		<b>44</b>
<b>Table A.3 -- Data for fuel flow factor .....</b>		<b>44</b>
A.3.2.4	Mechanical ventilation .....	44
<b>Table A.4 --Values for fctrl .....</b>		<b>45</b>
<b>Table A.5 -- Values for fsys .....</b>		<b>45</b>
A.3.3	System design data .....	45
A.3.3.1	Supply air temperature control .....	45
A.3.3.2	Exposure to wind .....	45
<b>Table A.6 -- Identifiers for SHIELD_CLASS .....</b>		<b>45</b>
A.3.3.3	Pressure coefficients associated to an air flow path .....	45
<b>Table A.7 -- Dimensionless wind pressures coefficients .....</b>		<b>46</b>
<b>Table A.8 -- Dimensionless wind pressures coefficients for ventilation zone that cannot be cross-ventilated (fcross = 0) .....</b>		<b>46</b>
A.3.3.4	Difference of wind pressure coefficients .....	46
A.3.3.5	Pressure coefficient of the cowl at roof height .....	46
A.3.3.6	Correction coefficient for accounting for height of cowl above roof level .....	46
<b>Table A.9 -- Examples of Ccowl;height values .....</b>		<b>47</b>
A.3.3.7	Ventilation effectiveness .....	47

A.3.3.8	Airing factor .....	47
A.3.3.9	Cross-ventilation factor .....	47
<b>Table A.10 -- Cross-ventilation factor .....</b>		<b>47</b>
A.3.3.10	Number of window divisions .....	48
A.3.3.11	Stack effect in passive and hybrid duct .....	48
A.3.3.12	Distribution of vents .....	48
<b>Table A.11 -- Distribution of vents .....</b>		<b>48</b>
A.3.3.13	Reference pressure for the envelope airtightness index .....	48
A.3.3.14	Flow exponent through leaks .....	48
A.3.3.15	Leakage coefficient of the ventilation zone .....	48
A.3.3.16	Envelope leakage distribution .....	48
<b>Table A.12 -- Envelope leakage distribution .....</b>		<b>48</b>
A.3.3.17	Typical internal doorway area .....	49
A.3.4	Operating conditions data .....	49
A.3.4.1	Maximum wind speed for cross-ventilation calculation .....	49
A.3.4.2	Wind speed correction factors .....	49
<b>Table A.13 -- Correction factor Crgh;10;site .....</b>		<b>49</b>
A.3.4.3	Ventilation system operation .....	49
<b>Table A.14 -- Identifiers for VENT_SYS_OP .....</b>		<b>49</b>
A.4	Input data method 2 .....	49
<b>Annex B (informative) Input and method selection data sheet - Default choices .....</b>		<b>50</b>
B.1	General .....	50
B.2	References .....	51
<b>Table B.1 --References .....</b>		<b>51</b>
B.3	Input data method 1 .....	51
B.3.1	Product description data .....	51
B.3.2	Product technical data .....	51
B.3.2.1	Discharge coefficient for vents, air terminal devices, windows .....	51
B.3.2.2	Airflow exponent for vents, air terminal devices, windows .....	52
B.3.2.3	Combustion air flows factors .....	52
<b>Table B.2 -- Data for appliance system factor .....</b>		<b>52</b>
<b>Table B.3 -- Data for fuel flow factor .....</b>		<b>52</b>
B.3.2.4	Mechanical ventilation .....	53
<b>Table B.4 -- Values for fctrl .....</b>		<b>53</b>
<b>Table B.5 -- Values for fsys .....</b>		<b>53</b>
B.3.3	System design data .....	53
B.3.3.1	Supply air temperature control .....	53
B.3.3.2	Exposure to wind .....	54
<b>Table B.6 -- Identifiers for SHIELD_CLASS .....</b>		<b>54</b>
B.3.3.3	Pressure coefficients associated to an air flow path .....	54
<b>Table B.7 -- Dimensionless wind pressures coefficients .....</b>		<b>54</b>
<b>Table B.8 -- Dimensionless wind pressures for ventilation zone that cannot be cross- ventilated (fcross = 0) .....</b>		<b>54</b>
B.3.3.4	Difference of wind pressure coefficients .....	54
B.3.3.5	Pressure coefficient of the cowl at roof height .....	55
B.3.3.6	Correction coefficient for accounting for height of cowl above roof level .....	55

<b>Table B.9 -- Examples of <math>C_{cowl; height}</math> values .....</b>	<b>55</b>
B.3.3.7    Ventilation effectiveness .....	55
B.3.3.8    Airing factor .....	55
B.3.3.9    Cross-ventilation factor .....	55
<b>Table B.10 -- Cross-ventilation factor .....</b>	<b>56</b>
B.3.3.10   Number of window divisions .....	56
B.3.3.11   Stack effect in passive and hybrid duct .....	56
B.3.3.12   Distribution of vents .....	56
<b>Table B.11 -- Distribution of vents .....</b>	<b>56</b>
B.3.3.13   Reference pressure for the envelope airtightness index .....	57
B.3.3.14   Flow exponent through leaks .....	57
B.3.3.15   Leakage coefficient of the ventilation zone .....	57
B.3.3.16   Envelope leakage distribution .....	57
<b>Table B.12 -- Envelope leakage distribution .....</b>	<b>57</b>
B.3.3.17   Typical internal doorway area .....	58
B.3.4       Operating conditions data .....	58
B.3.4.1      Maximum wind speed for cross-ventilation calculation .....	58
B.3.4.2      Wind speed correction factors .....	58
<b>Table B.13 -- Correction factor <math>C_{RH; 10; site}</math> .....</b>	<b>58</b>
B.3.4.3      Ventilation system operation .....	58
<b>Table B.14 -- Identifiers for VENT_SYS_OP .....</b>	<b>58</b>
B.4          Input data method 2 .....	58
<b>Bibliography .....</b>	<b>59</b>