

# ISO 5222-1:2023-08 (E)

## Heat recovery ventilators and energy recovery ventilators - Testing and calculating methods for seasonal performance factor - Part 1: Sensible heating recovery seasonal performance factors of heat recovery ventilators (HRV)

---

Contents	Page
Foreword.....	iv
<b>1 Scope.....</b>	<b>1</b>
<b>2 Normative references.....</b>	<b>1</b>
<b>3 Terms and definitions.....</b>	<b>1</b>
<b>4 Symbols and abbreviated terms.....</b>	<b>2</b>
<b>5 Tests.....</b>	<b>3</b>
5.1 General requirements.....	3
5.2 Test conditions.....	3
5.3 Test methods.....	3
5.3.1 General.....	3
5.3.2 Energy saving stage limit temperature.....	4
5.3.3 Sensible heating recovery performance test.....	4
5.3.4 Determination of bypass outdoor temperature.....	4
5.3.5 Measurement of power input of heat recovery ventilator with bypass ventilation function.....	4
5.3.6 Determination of the frosting temperature by test.....	5
<b>6 Calculations.....</b>	<b>6</b>
6.1 Gross sensible heating recovery effectiveness ( $\epsilon_{sh}$ ).....	6
6.2 Sensible heating coefficient of energy.....	6
6.2.1 Sensible heating coefficient of energy: ducted ventilators.....	6
6.2.2 Sensible heating coefficient of energy: unducted ventilators.....	7
6.3 Calculation of seasonal performance factor of sensible heating recovery ( $F_{sh}$ ).....	7
6.3.1 Reference outdoor air heating load and sensible heating recovery capacity.....	7
6.3.2 The characteristics of sensible heating recovery capacity against outdoor temperature.....	8
6.3.3 Power input characteristics of sensible heating recovery against outdoor temperature.....	9
6.3.4 Outdoor temperature bin distribution for heating.....	10
6.3.5 Calculation of seasonal sensible heating recovery capacity ( $E_{sh}$ ).....	10
6.3.6 Calculation of seasonal sensible heating recovery power input ( $P_{in,E}$ ).....	10
6.3.7 Calculation of seasonal performance factor for sensible heating recovery ( $F_{sh}$ ).....	11
<b>7 Test report.....</b>	<b>11</b>
<b>Annex A (informative) The schematic diagram of HRV heating (H) operation.....</b>	<b>12</b>
<b>Annex B (informative) The default outdoor temperature bin distribution for heating.....</b>	<b>14</b>
<b>Annex C (normative) Method of determination of the temperature <math>T_{F,0}</math>.....</b>	<b>15</b>
<b>Annex D (informative) Calculating method for seasonal performance factor when setting a specific application heating load.....</b>	<b>16</b>
<b>Annex E (normative) Calculation of the bypass outdoor temperature.....</b>	<b>18</b>
<b>Annex F (informative) Report template.....</b>	<b>19</b>
<b>Bibliography.....</b>	<b>22</b>