

# DIN EN 13757-2:2005-02 (E)

## Communication systems for and remote reading of meters - Part 2: Physical and link layer; English version EN 13757-2:2004

---

<b>Inhalt</b>	<b>Seite</b>
<b>Foreword</b> .....	<b>3</b>
<b>Introduction</b> .....	<b>4</b>
<b>1 Scope</b> .....	<b>5</b>
<b>2 Normative references</b> .....	<b>5</b>
<b>3 Terms and definitions</b> .....	<b>5</b>
<b>4 Physical layer specifications</b> .....	<b>6</b>
<b>5 Link Layer (master and slave)</b> .....	<b>12</b>
<b>6 Tables and figures</b> .....	<b>17</b>
<b>Annex A (informative) Schematic implementation of slave</b> .....	<b>21</b>
<b>Annex B (informative) Protection against mains voltages</b> .....	<b>22</b>
<b>Annex C (informative) Slave powering options</b> .....	<b>23</b>
<b>Annex D (informative) Slave collision detect</b> .....	<b>24</b>
<b>Annex E (informative) Cable installation</b> .....	<b>25</b>
<b>Annex F (informative) Protocol examples</b> .....	<b>27</b>
<b>Bibliography</b> .....	<b>28</b>