

# DIN EN 13757-2:2005-02 (E)

## Communication systems for and remote reading of meters - Part 2: Physical and link layer; English version EN 13757-2:2004

---

<b>Inhalt</b>	<b>Seite</b>
Foreword .....	3
Introduction.....	4
1 <b>Scope</b> .....	5
2 <b>Normative references</b> .....	5
3 <b>Terms and definitions</b> .....	5
4 <b>Physical layer specifications</b> .....	6
5 <b>Link Layer (master and slave)</b> .....	12
6 <b>Tables and figures</b> .....	17
<b>Annex A</b> (informative) <b>Schematic implementation of slave</b> .....	21
<b>Annex B</b> (informative) <b>Protection against mains voltages</b> .....	22
<b>Annex C</b> (informative) <b>Slave powering options</b> .....	23
<b>Annex D</b> (informative) <b>Slave collision detect</b> .....	24
<b>Annex E</b> (informative) <b>Cable installation</b> .....	25
<b>Annex F</b> (informative) <b>Protocol examples</b> .....	27
<b>Bibliography</b> .....	28