

DIN EN 12097:2006-11 (E)

Ventilation for buildings - Ductwork - Requirements for ductwork components to facilitate maintenance of ductwork systems

| Contents | | Page |
|--|---|-------------|
| Foreword | | 3 |
| 1 | Scope | 4 |
| 2 | Normative references | 4 |
| 3 | Definition and symbols | 5 |
| 4 | Requirements | 5 |
| 4.1 | General | 5 |
| 4.2 | Openings | 5 |
| 4.2.1 | General | 5 |
| 4.2.2 | Installation and location of openings | 6 |
| 4.2.3 | Dimensions | 6 |
| 4.3 | Duct-mounted components | 8 |
| 4.4 | Location and frequency of access panels | 9 |
| 4.5 | Screws and rivets | 9 |
| Annex A (informative) Service and access recommendations | | 10 |
| Bibliography | | 11 |