

DIN EN 15242:2007-09 (E)

Ventilation for buildings - Calculation methods for the determination of air flow rates in buildings including infiltration

Contents		Page
Foreword		3
Introduction		4
1	Scope	6
2	Normative references	6
3	Terms and definitions	7
4	Symbols and abbreviations	9
5	General approach	10
6	Instantaneous calculation (iterative method)	12
6.1	Basis of the calculation method	12
6.2	Mechanical air flow calculation	13
6.3	Passive and hybrid duct ventilation	17
6.4	Combustion air flows	23
6.5	Air flow due to windows opening	25
6.6	Exfiltration and infiltration using iterative method	27
6.7	Exfiltration and infiltration calculation using direct method	28
7	Applications	30
7.1	General	30
7.2	Energy	30
7.3	Heating load	35
7.4	Cooling loads	35
7.5	Summer comfort	35
7.6	Indoor air quality	36
Annex A (normative) Data on wind pressure coefficients		37
Annex B (normative) Leakages characteristics		43
Annex C (normative) Calculation of recirculation coefficient C_{rec}		46
Annex D (normative) Conversion formulas		48
Annex E (informative) Examples of fuel flow factor for residential buildings		51
Bibliography		52