ISO/IEC TR 22767:2005-08 (E)

Information technology - Telecommunications and information exchange between systems - Using CSTA for SIP phone user agents (uaCSTA)

Contents

Page

Foreword vii

Introduction viii

1 Scope 1

2 Purpose 1

3 Normative references 2

4 Terminology 2
4.1 General terms 2
4.2 SIP/CSTA Terminology Mappings 3

5 Example Environments for uaCSTA 3
5.1 Controlling and Observing a SIP Phone 3
5.2 Controlling and Observing a SIP Phone by Augmenting B2BUA Functionality 4
5.3 Controlling a PBX Phone 4

6 Example User Agent Configurations 5
6.1 Single Line Phone UA 5
6.2 Multi Line Phone UA 6
6.3 Bridged Appearance Phone and other Advanced UA Configurations 6

7 SIP Transport Mechanism for CSTA Messages 7
7.1 Establishing a CSTA Application Session 7
7.2 Transporting CSTA Service Requests and Responses 8
7.3 Starting a Monitor and Transporting CSTA Events 9

8 uaCSTA Profiles 9
8.1 Minimal uaCSTA Call Control Profile 10
8.1.1 Services 10
8.1.2 Events 10
8.2 Basic uaCSTA Call Control Profile 10
8.2.1 Services 10
8.2.2 Events 11
8.3 Advanced uaCSTA Call Control Profile 11
8.3.1 Services 11
8.3.2 Events 12
8.4 Conferencing uaCSTA Call Control Feature Profile 12
8.4.1 Services 12
8.4.2 Events 13
8.5 Basic uaCSTA Device Feature Profile 13
8.5.1 Services 13
8.5.2 Events 13
8.6 Speaker uaCSTA Device Feature Profile 13
8.6.1 Services 13
8.6.2 Events 13

9 CSTA Calls and Connections 13
9.1 CSTA Connection State Model 14

9.2 Connection State Transitions for CSTA Calls 14
9.2.1 Incoming Call 14
9.2.2 Outgoing Call 15

10 Call Control 15
10.1 Alternate Call 15
10.1.1 Service Request 16
10.1.2 Positive Service Response 16
10.1.3 Negative Service Response 16
10.2 Answer Call 17
10.2.1 Service Request 17
10.2.2 Positive Service Response 18
10.2.3 Negative Service Response 18
10.3 Clear Connection 19
10.3.1 Service Request 19
10.3.2 Positive Service Response 19
10.3.3 Negative Service Response 19
10.4 Consultation Call 20
10.4.1 Service Request 20
10.4.2 Positive Service Response 21
10.4.3 Negative Service Response 21
10.5 Deflect Call 22
10.5.1 Service Request 22
10.5.2 Positive Service Response 22
10.5.3 Negative Service Response 23
10.6 Generate Digits 23
10.6.1 Service Request 24
10.6.2 Positive Service Response 24
10.6.3 Negative Service Response 24
10.7 Hold Call 25
10.7.1 Service Request 25
10.7.2 Positive Service Response 25
10.7.3 Negative Service Response 26
10.8 Make Call 26
10.8.1 Service Request 26
10.8.2 Positive Service Response 27
10.8.3 Negative Service Response 27
10.9 Reconnect Call 28
10.9.1 Service Request 28
10.9.2 Positive Service Response 29
10.9.3 Negative Service Response 29
10.10 Retrieve Call 30
10.10.1 Service Request 30
10.10.2 Positive Service Response 30
10.10.3 Negative Service Response 30
10.11 Single Step Transfer Call 31
10.11.1 Service Request 31
10.11.2 Positive Service Response 32
10.11.3 Negative Service Response 32
10.12 Transfer Call 33
10.12.1 Service Request 33
10.12.2 Positive Service Response 34
10.12.3 Negative Service Response 34

11 Physical Phone Features 35
11.1 Get Message Waiting Indicator 35
11.1.1 Service Request 36
11.1.2 Service Response 36
11.2 Set Message Waiting Indicator 36
11.2.1 Service Request 36
11.2.2 Service Response 37
11.3 Get Speaker Mute 37

11.3.1 Service Request 37
11.3.2 Service Response 37
11.4 Set Speaker Mute 38
11.4.1 Service Request 38
11.4.2 Service Response 38
11.5 Get Speaker Volume 39
11.5.1 Service Request 39
11.5.2 Service Response 39
11.6 Set Speaker Volume 40
11.6.1 Service Request 40
11.6.2 Service Response 40

12 Logical Phone Features 41
12.1 Get Do Not Disturb 41
12.1.1 Service Request 41
12.1.2 Service Response 41
12.2 Set Do Not Disturb 41
12.2.1 Service Request 42
12.2.2 Service Response 42
12.3 Get Forwarding 42
12.3.1 Service Request 42
12.3.2 Service Response 42
12.4 Set Forwarding 43
12.4.1 Service Request 43
12.4.2 Service Response 44

13 Monitoring Services and Events 44
13.1 Monitor Start 44
13.1.1 Service Request 44
13.1.2 Positive Service Response 45
13.1.3 Negative Service Response 45
13.2 Monitor Stop 46
13.2.1 Service Request 46
13.2.2 Positive Service Response 47
13.2.3 Negative Service Response 47
13.3 Events 47

14 Snapshot Services 48
14.1 Snapshot Device 48
14.1.1 Service Request 48
14.1.2 Positive Service Response 48
14.1.3 Negative Service Response 51

15 Discovery and System Status Services 51
15.1 Get CSTA Features 51
15.1.1 Service Request 52
15.1.2 Service Response 52
15.1.3 Negative Service Response 53
15.2 Request System Status 53
15.2.1 Service Request 53
15.2.2 Service Response 53
15.2.3 Negative Service Response 54
15.3 System Status 54
15.3.1 Service Request 54
15.3.2 Positive Service Response 55
15.3.3 Negative Service Response 55

16 ECMA-323 Illustrative Examples 55
16.1 Controlling a SIP UA 55
16.1.1 Creating an Application Session, Establishing a Monitor for a SIP Phone 56
16.1.2 Creating a Call from a SIP UA, Clearing a Call at a SIP UA 58
16.1.3 Answering and Clearing an Incoming Call at a UA 63

16.1.4 Answering an Incoming Call at a UA (no CSTA monitor or CSTA events) 65
16.1.5 Examples of Exception Conditions at a SIP UA 67
16.2 Controlling a PBX Phone 68
16.2.1 Creating an Application Session, Establishing a Monitor for a PBX Phone 69
16.2.2 Creating a Call from a PBX Phone, Clearing a Call at a PBX Phone 71
16.2.3 Answering and Clearing an Incoming Call at a PBX Phone 75
16.2.4 Examples of Exception Conditions at a PBX Phone 78

Annex A (informative) Example use of SIP and TEL URIs 80