

# ISO 13860:2016-03 (E)

## Machinery for forestry - Forwarders - Terms, definitions and commercial specifications

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>2.1</b>	<b>Basic definitions .....</b>	<b>1</b>
<b>2.2</b>	<b>Masses .....</b>	<b>1</b>
<b>2.3</b>	<b>Main machine dimensions .....</b>	<b>2</b>
<b>2.4</b>	<b>Loader dimensions .....</b>	<b>6</b>
<b>2.5</b>	<b>Bogie and load space dimensions .....</b>	<b>7</b>
<b>3</b>	<b>Required information .....</b>	<b>8</b>
Bibliography .....		12