

# DIN EN 1501-4:2023-07 (E)

## Refuse collection vehicles - General requirements and safety requirements - Part 4: Noise test code for refuse collection vehicles

---

<b>Contents</b>		<b>Page</b>
European foreword .....		3
Introduction .....		5
1	Scope .....	6
2	Normative references .....	6
3	Terms and definitions .....	7
4	Determination of the A-weighted emission sound pressure level(s) at working station(s) ...	8
4.1	General .....	8
4.2	Measurement positions .....	8
4.2.1	Working station(s) outside the cab .....	8
4.2.2	Working station(s) in the cab .....	9
5	Determination of the A-weighted sound power level .....	10
5.1	General .....	10
5.2	Travel cycle .....	10
5.2.1	Travel path .....	10
5.2.2	Measuring path .....	11
5.3	Microphone positions .....	12
6	Installation and operating conditions .....	14
6.1	Installation conditions .....	14
6.2	Operating conditions .....	14
6.2.1	General operating conditions .....	14
6.2.2	Specific operating conditions for the emission sound pressure level(s) at working station(s) measurement .....	15
6.2.3	Specific operating conditions for the sound power level measurement .....	15
7	Measurement uncertainties .....	16
7.1	Measurement of emission sound pressure level(s) at working station(s) .....	16
7.2	Measurement of sound power level .....	16
8	Information to be recorded and reported .....	16
9	Information for use, noise emission declaration and labelling .....	17
9.1	Information for use including noise emission declaration and sales literature .....	17
9.2	Labelling .....	18
Annex A (informative) Test report form .....		19
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC .....		22
Bibliography .....		23