ISO 20210:2015-08 (E)

Space data and information transfer systems - Mission Operations Message Abstraction Layer - JAVA API

Contents

Page

1 INTRODUCTION 1-1

1.1 PURPOSE OF THIS RECOMMENDED PRACTICE 1-1
1.2 SCOPE 1-1
1.3 APPLICABILITY 1-1
1.4 RATIONALE 1-1
1.5 DOCUMENT STRUCTURE 1-1
1.6 DEFINITIONS 1-2
1.7 CONVENTIONS 1-2
1.8 REFERENCES 1-4

2 OVERVIEW 2-1

2.1 GENERAL 2-1
2.2 MO SERVICE FRAMEWORK JAVA MAPPING 2-3
2.3 MAPPING FROM MAL DOCUMENT 2-5

3 MAL API 3-1

3.1 GENERAL 3-1
3.2 MAL PACKAGE 3-3
3.3 DATA STRUCTURES PACKAGE 3-40
3.4 CONSUMER PACKAGE 3-58
3.5 PROVIDER PACKAGE 3-94
3.6 BROKER PACKAGE 3-134

4 SERVICE MAPPING 4-1

4.1 OVERVIEW 4-1
4.2 DEFINITION 4-1
4.3 CONSUMER 4-8
4.4 PROVIDER 4-25
4.5 DATA STRUCTURES 4-40
4.6 ELEMENT FACTORY CLASSES 4-50
4.7 MULTIPLE ELEMENT BODY CLASSES 4-51
4.8 HELPER AND ELEMENT FACTORY CLASSES 4-53

5 TRANSPORT API 5-1

5.1 GENERAL 5-1
5.2 CLASSES AND INTERFACES 5-1

Section Page

6 ACCESS CONTROL API 6-1

6.1 GENERAL 6-1
6.2 CLASSES AND INTERFACES 6-1

7 ENCODING API 7-1

7.1 OVERVIEW 7-1
7.2 CLASSES AND INTERFACES 7-1

ANNEX A DEFINITION OF ACRONYMS (INFORMATIVE) A-1
ANNEX B INFORMATIVE REFERENCES (INFORMATIVE) B-1
ANNEX C SECURITY, SANA, AND PATENT CONSIDERATIONS (INFORMATIVE) C-1
ANNEX D CODE EXAMPLE (INFORMATIVE) D-1

Figure

2-1 Mission Operations Services Concept Document Set 2-1
2-2 Relationship of MO Books 2-2
2-3 Overview of the Mission Operations Service Framework 2-3
2-4 MO Framework Java Mapping 2-4
3-1 Relationships between the API Main Interfaces 3-2
4-1 Relationships between the Stub Classes and Interfaces 4-8
4-2 Relationships between the Skeleton Classes and Interfaces (Delegation Pattern) 4-26
4-3 Relationships between the Skeleton Classes and Interfaces (Inheritance Pattern) 4-26
4-4 Multi-Binding Service Provider 4-27

Table

1-1 Variable Value Case Rules 1-4
3-1 API Main Interfaces 3-1
3-2 MALContextFactory ‘registerFactoryClass’ Parameter 3-4
3-3 MALContextFactory ‘deregisterFactoryClass’ Parameter 3-4
3-4 MALContextFactory ‘createMALContext’ Parameter 3-6
3-5 MALContextFactory ‘registerArea’ Parameter 3-6
3-6 MALContextFactory ‘lookupArea’ Parameters 3-7
3-7 MALContextFactory ‘registerError’ Parameters 3-8
3-8 MALContextFactory ‘lookupError’ Parameter 3-8
3-9 MALContext ‘getTransport’ Parameters 3-11

Table Page

3-10 MALService Attributes 3-12
3-11 MALService Constructor Parameters 3-13
3-12 MALService ‘setArea’ Parameter 3-15
3-13 MALService ‘addOperation’ Parameter 3-15
3-14 MALOperation Attributes 3-16
3-15 MALOperation Constructor Parameters 3-16
3-16 MALOperation ‘getOperationStage’ Parameter 3-18
3-17 MALOperation ‘setService’ Parameter 3-19
3-18 Interaction Stages Constants 3-20
3-19 Operation stages 3-21
3-20 MAL<<Ip>>Operation Constructor Parameters 3-21
3-21 MALOperationStage Attributes 3-23
3-22 MALOperationStage Constructor Parameters 3-24
3-23 MALOperation ‘setOperation’ Parameter 3-25
3-24 MALService Attributes 3-26
3-25 MALArea Constructor Parameters 3-26
3-26 MALArea ‘addService’ Parameter 3-27
3-27 MALService Constructor Parameters 3-28
3-28 MALException Constructor Parameters 3-30
3-29 MALInteractionException Constructor Parameter 3-31
3-30 MALElementFactoryRegistry ‘registerElementFactory’ Parameters 3-32
3-31 MALElementFactoryRegistry ‘lookupElementFactory’ Parameter 3-33
3-32 MALElementFactoryRegistry ‘deregisterElementFactory’ Parameter 3-33
3-33 MALEncoder and MALDecoder Variables 3-34
3-34 MALEncoder ‘encode[Nullable]<<Attribute>>’ Parameter 3-35
3-35 MALListEncoder ‘createListEncoder’ Parameter 3-36
3-36 MALListDecoder ‘createListDecoder’ Parameter 3-36
3-37 MALEncoder ‘encode[Nullable]Element’ Parameter 3-37
3-38 MALDecoder ‘decode[Nullable]Element’ Parameter 3-37
3-39 MALEncoder ‘encode[Nullable]Attribute’ Parameter 3-38
3-40 Element ‘encode’ Parameter 3-41
3-41 Element ‘decode’ Parameter 3-42
3-42 Enumeration Constructor Parameter 3-44
3-43 MAL::Attribute Types Mapped to a Java Type 3-45
3-44 Union Variables 3-46
3-45 Union Constructor Parameter 3-46
3-46 Blob Byte Array Constructor Parameter 3-49
3-47 Blob URL Constructor Parameter 3-50
3-48 MAL::Attribute Types Represented by a Specific Class 3-53
3-49 Initial Value Assigned by the <<Attribute>> Empty Constructor 3-54
3-50 MALConsumerManager ‘createConsumer’ Parameters 3-59

Table Page

3-51 QoS Properties 3-60
3-52 MALConsumer ‘send’ Parameters 3-62
3-53 MALConsumer ‘submit’ Parameters 3-63
3-54 MALConsumer ‘request’ Parameters 3-64
3-55 MALConsumer ‘invoke’ Parameters 3-66
3-56 MALConsumer ‘progress’ Parameters 3-67
3-57 MALConsumer ‘register’ Parameters 3-68
3-58 MALConsumer ‘deregister’ Parameters 3-70
3-59 MALConsumer ‘asyncSubmit’ Parameters 3-71
3-60 MALConsumer ‘asyncRequest’ Parameters 3-72
3-61 MALConsumer ‘asyncInvoke’ Parameters 3-73
3-62 MALConsumer ‘asyncProgress’ Parameters 3-75
3-63 MALConsumer ‘asyncRegister’ Parameters 3-76
3-64 MALConsumer ‘asyncDeregister’ Parameters 3-77
3-65 MALConsumer ‘continueInteraction’ Parameters 3-78
3-66 MALConsumer ‘setTransmitErrorListener’ Parameter 3-79
3-67 MALInteractionListener ‘submitAckReceived’ Parameters 3-81
3-68 MALInteractionListener ‘submitErrorReceived’ Parameters 3-81
3-69 MALInteractionListener ‘requestResponseReceived’ Parameters 3-82
3-70 MALInteractionListener ‘requestErrorReceived’ Parameters 3-83
3-71 MALInteractionListener ‘invokeAckReceived’ Parameters 3-83
3-72 MALInteractionListener ‘invokeAckErrorReceived’ Parameters 3-84
3-73 MALInteractionListener ‘invokeResponseReceived’ Parameters 3-85
3-74 MALInteractionListener ‘invokeResponseErrorReceived’ Parameters 3-85
3-75 MALInteractionListener ‘progressAckReceived’ Parameters 3-86
3-76 MALInteractionListener ‘progressAckErrorReceived’ Parameters 3-87
3-77 MALInteractionListener ‘progressUpdateReceived’ Parameters 3-87
3-78 MALInteractionListener ‘progressUpdateErrorReceived’ Parameters 3-88
3-79 MALInteractionListener ‘progressResponseReceived’ Parameters 3-89
3-80 MALInteractionListener ‘progressResponseErrorReceived’ Parameters 3-89
3-81 MALInteractionListener ‘registerAckReceived’ Parameters 3-90
3-82 MALInteractionListener ‘registerErrorReceived’ Parameters 3-91
3-83 MALInteractionListener ‘notifyReceived’ Parameters 3-91
3-84 MALInteractionListener ‘notifyErrorReceived’ Parameters 3-92
3-85 MALInteractionListener ‘deregisterAckReceived’ Parameters 3-92
3-86 MALProviderManager ‘createProvider’ Parameters 3-95
3-87 MALProvider ‘createPublisher’ Parameters 3-99
3-88 MALProvider ‘setTransmitErrorListener’ Parameter 3-100
3-89 MALInteractionHandler ‘malInitialize’ Parameter 3-103
3-90 MALInteractionHandler ‘handleSend’ Parameters 3-103
3-91 MALInteractionHandler ‘handleSubmit’ Parameters 3-104

Table Page

3-92 MALInteractionHandler ‘handleRequest’ Parameters 3-105
3-93 MALInteractionHandler ‘handleInvoke’ Parameters 3-105
3-94 MALInteractionHandler ‘handleProgress’ Parameters 3-106
3-95 MALInteractionHandler ‘malFinalize’ Parameter 3-107
3-96 MALInteractionHandler ‘get/setQoSProperty’ Parameters 3-108
3-97 MALSubmit ‘sendError’ Parameter 3-109
3-98 MALResponse ‘sendResponse’ Parameter 3-111
3-99 MALResponse ‘sendError’ Parameter 3-112
3-100 MALInvoke ‘sendAcknowledgement’ Parameters 3-113
3-101 MALProgress ‘sendUpdate’ Parameter 3-115
3-102 MALProgress ‘sendUpdateError’ Parameter 3-116
3-103 MALPublisher ‘publish’ Parameters 3-117
3-104 MALPublisher ‘register’ Parameters 3-118
3-105 MALPublisher ‘asyncRegister’ Parameters 3-120
3-106 MALPublisher ‘asyncDeregister’ Parameter 3-121
3-107 MALPublishInteractionListener ‘publishRegisterAckReceived’ Parameters 3-123
3-108 MALPublishInteractionListener ‘publishRegisterErrorReceived’ Parameters 3-123
3-109 MALPublishInteractionListener ‘publishErrorReceived’ Parameters 3-124
3-110 MALPublishInteractionListener ‘publishDeregisterAckReceived’ Parameters 3-125
3-111 MALProviderSet Constructor Parameter 3-125
3-112 MALProviderSet ‘createPublisherSet’ Parameters 3-126
3-113 MALProviderSet ‘addProvider’ Parameter 3-127
3-114 MALProviderSet ‘removeProvider’ Parameter 3-128
3-115 MALPublisherSet Constructor Parameters 3-129
3-116 MALPublisherSet ‘createPublisher’ Parameter 3-129
3-117 MALPublisherSet ‘deletePublisher’ Parameter 3-130
3-118 MALPublisherSet ‘publish’ Parameters 3-131
3-119 MALPublisherSet ‘register’ Parameters 3-131
3-120 MALPublisherSet ‘asyncRegister’ Parameters 3-132
3-121 MALPublisherSet ‘asyncDeregister’ Parameter 3-133
3-122 MALBrokerManager ‘createBroker’ Parameter 3-135
3-123 MALBrokerBinding ‘createBrokerBinding’ Parameters 3-136
3-124 MALBrokerBinding ‘sendNotify’ Parameters 3-139
3-125 MALBrokerBinding ‘sendNotifyError’ Parameters 3-140
3-126 MALBrokerBinding ‘sendPublishError’ Parameters 3-142
3-127 MALBrokerBinding ‘setTransmitErrorListener’ Parameter 3-143
3-128 MALBrokerHandler ‘malInitialize’ Parameter 3-145
3-129 MALBrokerHandler ‘handleRegister’ Parameters 3-145
3-130 MALBrokerHandler ‘handlePublishRegister’ Parameters 3-146
3-131 MALBrokerHandler ‘handlePublish’ Parameters 3-147
3-132 MALBrokerHandler ‘handleDeregister’ Parameters 3-148

Table Page

3-133 MALBrokerHandler ‘handlePublishDeregister’ Parameters 3-148
3-134 MALBrokerHandler ‘malFinalize’ Parameter 3-149
4-1 Service Mapping Variables 4-3
4-2 Area Classes 4-7
4-3 Service Classes 4-7
4-4 <<Service>>Stub Attribute 4-21
4-5 <<Op>> Publisher Attribute 4-30
4-6 <<Op>>Publisher constructor Parameter 4-30
4-7 <<Op>>Publisher ‘publish’ Parameters 4-31
4-8 Invoke <<Op>>Interaction Attribute 4-32
4-9 Progress <<Op>>Interaction Attribute 4-34
4-10 <<Service>>InheritanceSkeleton Attributes 4-36
4-11 <<Service>>DelegationSkeleton Attributes 4-39
5-1 MALTransportFactory Attributes 5-1
5-2 MALTransportFactory ‘registerFactoryClass’ Parameters 5-2
5-3 MALTransportFactory ‘deregisterFactoryClass’ Parameter 5-2
5-4 MALTransportFactory Constructor Parameter 5-3
5-5 MALTransportFactory ‘newFactory’Parameter 5-4
5-6 MALTransportFactory ‘createTransport’ Parameter 5-5
5-7 MALTransport ‘createEndpoint’ Parameters 5-6
5-8 MALTransport ‘getEndpoint’ Parameters 5-7
5-9 MALTransport ‘deleteEndpoint’ Parameter 5-7
5-10 MALTransport ‘isSupportedQoSLevel’ Parameter 5-8
5-11 MALTransport ‘isSupportedInteractionType’ Parameter 5-9
5-12 MALTransport ‘createBroker’ Parameters 5-10
5-13 MALEndpoint ‘createMessage’ Parameters 5-15
5-14 MALEndpoint ‘sendMessage’ Parameters 5-16
5-15 MALEndpoint ‘sendMessages’ Parameters 5-17
5-16 MALEndpoint ‘setMessageListener’ Parameter 5-17
5-17 MALMessageBody ‘getBodyElement’ Parameters 5-20
5-18 MALMessageBody ‘getEncodedBodyElement’ Parameter 5-20
5-19 MALPublishBody ‘getUpdateLists’ Parameter 5-23
5-20 MALPublishBody ‘getUpdateList’ Parameter 5-23
5-21 MALPublishBody ‘getUpdate’ Parameter 5-24
5-22 MALPublishBody ‘getEncodedUpdate’ Parameter 5-25
5-23 MALEncodedElement Constructor Parameter 5-27
5-24 MALMessageListener ‘onMessage’ Parameters 5-29
5-25 MALMessageListener ‘onMessages’ Parameters 5-29
5-26 MALMessageListener ‘onInternalError’ Parameters 5-30
5-27 MALTransmitErrorException Constructor Parameters 5-30
5-28 MALTransmitMultipleErrorException Constructor Parameter 5-32

Table Page

5-29 MALEncodedElementList Constructor Parameters 5-33
5-30 MALEncodedBody Constructor Parameter 5-33
5-31 MALTransmitErrorListener ‘onTransmitError’ Parameters 5-34
6-1 MALAccessControlFactory ‘registerFactoryClass’ Parameters 6-2
6-2 MALAccessControlFactory ‘deregisterFactoryClass’ Parameter 6-2
6-3 MALAccessControlFactory ‘createAccessControl’ Parameter 6-3
6-4 MALAccessControl ‘check’ Parameter 6-4
6-5 MALCheckErrorException Constructor Parameters 6-5
7-1 MALElementStreamFactory ‘registerFactoryClass’ Parameters 7-2
7-2 MALElementStreamFactory ‘deregisterFactoryClass’ Parameters 7-3
7-3 MALElementStreamFactory Creation Parameters 7-3
7-4 MALElementStreamFactory ‘init’ Parameters 7-5
7-5 MALElementStreamFactory ‘createInputStream’ Parameter 7-5
7-6 MALElementStreamFactory ‘createOutputStream’ Parameter 7-6
7-7 MALElementStreamFactory ‘encode’ Parameters 7-7
7-8 MALElementInputStream ‘readElement’ Parameters 7-8
7-9 MALElementOutputStream ‘writeElement’ Parameters 7-9
7-10 MALEncodingContext Attributes 7-11
C-1 JavaBindingNamespace Initial Values C-3