DIN EN 16603-50-12:2020-06 (E)

Space engineering - SpaceWire - Links, nodes, routers and networks; English version EN 16603-50-12:2020

Table of contents

European Foreword 7

1 Scope 8

2 Normative references 9

3 Terms, definitions and abbreviated terms 10

3.1 Terms from other standards 10

3.2 Terms specific to the present standard 10

3.3 Abbreviated terms 20

3.4 Conventions 21

3.4.1 Numbers 21

3.4.2 Differential signals 21

3.4.3 Order of sending bits in symbols 21

3.4.4 Graphical representation of packets 22

3.4.5 State diagram notation 22

3.4.6 UML diagram notation 23

3.5 Nomenclature 24

4 Overview of SpaceWire 25

4.1 Introduction 25

4.2 SpaceWire Spacecraft Data-Handling Network 25

4.2.1 The Rationale for SpaceWire 25

4.2.2 Example SpaceWire Application 26

4.2.3 How SpaceWire Works 28

5 Requirements 33

5.1 Overview 33

5.2 Protocol stack and interface architecture 33

5.2.1 Protocol stack 33

5.2.2 Network layer 34

5.2.3 Data Link layer 34

5.2.4 Encoding layer 35

5.2.5 Physical layer 35

5.2.6 Management Information Base 36
5.2.7 Service interfaces 36
5.2.8 SpaceWire Port architecture 36
5.3 Physical layer 37
5.3.1 Introduction 37
5.3.2 Cables 38
5.3.3 Connectors 41
5.3.4 Cable assemblies 45
5.3.5 PCB tracks 50
5.3.6 Line drivers and receivers 51
5.3.7 Data-Strobe skew 59
5.3.8 Physical layer management parameters 62
5.4 Encoding layer 63
5.4.1 Introduction 63
5.4.2 Serialisation and de-serialisation 63
5.4.3 Character and control code encoding 63
5.4.4 Data strobe encoding and decoding 66
5.4.5 First Null 68
5.4.6 Null detection 68
5.4.7 Parity error 69
5.4.8 Disconnect 69
5.4.9 ESC error 69
5.4.10 Data signalling rate 70
5.4.11 Encoding layer management parameters 71
5.5 Data link layer 71
5.5.1 Introduction 71
5.5.2 Data link layer interfaces 71
5.5.3 Data link layer management interface 72
5.5.4 Flow control 73
5.5.5 Flow control errors 74
5.5.6 Sending priority 75
5.5.7 Link initialisation behaviour 75
5.5.8 Link error recovery 80
5.5.9 Accepting broadcast codes for sending 82
5.6 SpaceWire network layer 82
5.6.1 Introduction 82
5.6.2 SpaceWire packets 83

5.6.3 Broadcast codes 83
5.6.4 SpaceWire time-codes 84
5.6.5 SpaceWire distributed interrupts 87
5.6.6 SpaceWire nodes 94
5.6.7 SpaceWire node management parameters 96
5.6.8 SpaceWire routing 96
5.6.9 SpaceWire routing switch management parameters 104
5.6.10 SpaceWire network 104
5.7 SpaceWire management information base 106
5.7.1 Introduction 106
5.7.2 General 106
5.7.3 Physical layer management parameters 106
5.7.4 Encoding layer management parameters 106
5.7.5 Data link layer management parameters 106
5.7.6 Network layer management parameters 106
6 Service interfaces 107
6.1 Network layer service interface 107
6.1.1 Packet service interface 107
6.1.2 Time-code service interface 108
6.1.3 Distributed interrupt service interface 109
6.2 Data link layer service interface 111
6.2.1 N-Char service interface 111
6.2.2 Broadcast code service interface 113
6.3 Encoding layer service interface 114
6.3.1 Encoding service interface 114
6.3.2 Decoding service interface 115
6.4 Physical layer service interface 117
6.4.1 Line transmit service interface 117
6.4.2 Line receive service interface 118
6.5 Management information base service interface 119
6.5.1 Set parameter service interface 119
6.5.2 Get parameter service interface 119
Annex A (informative) Technical Changes 121
Bibliography 123

Figures

Figure 3-1: Convention for first bit to be sent 21
Figure 3-2: Graphical packet notation 22
Figure 3-3: State diagram style 22
Figure 3-4: UML notation 23
Figure 4-1: Example SpaceWire Architecture without redundancy 27
Figure 4-2: SpaceWire Packet Format 29
Figure 4-3: Path Addressing 31
Figure 4-4 Logical Addressing 32
Figure 5-1: SpaceWire protocol stack 34
Figure 5-2: SpaceWire port architecture 37
Figure 5-3: SpaceWire connector contact identification 44
Figure 5-4: SpaceWire cable assembly Type A 47
Figure 5-5: SpaceWire cable assembly Type AL 49
Figure 5-6: SpaceWire LVDS 53
Figure 5-7: LVDS line driver output signals 54
Figure 5-8: LVDS line driver differential output signal 56
Figure 5-9: Physical layer components 59
Figure 5-10: Skew and jitter 62
Figure 5-11: Data character encoding 64
Figure 5-12: Control character encoding 65
Figure 5-13: Null control code encoding 65
Figure 5-14: Broadcast code encoding 66
Figure 5-15: Parity coverage 66
Figure 5-16: Data-Strobe (DS) encoding 67
Figure 5-17: Data and strobe signals for first Null 68
Figure 5-18: Null detection sequence 69
Figure 5-19: Link initialisation behaviour 76
Figure 5-20: Link error recovery behaviour 81
Figure 5-21: SpaceWire packet format 83
Figure 5-22: Specialisations and relationships of a SpaceWire broadcast code 84
Figure 5-23 Network layer time-code 85
Figure 5-24: Network layer interrupt 88
Figure 5-25: Network layer interrupt acknowledgement code 89
Figure 5-26: Components and specialisations of a SpaceWire node 95
Figure 5-27: Components of a SpaceWire routing switch 97
Figure 5-28: Components of a SpaceWire network 105

Tables

Table 5-1: Constants for a SpW cable using 28 AWG differential pairs 39
Table 5-2: Insertion loss values 28AWG SpW cable.....40
Table 5-3: Constants for a SpaceWire cable using 26 AWG differential pairs.....40
Table 5-4: Insertion loss values for 26 AWG SpaceWire cable.....40
Table 5-5: Cable PSNEXT specification 41
Table 5-6: Cable PSELFEXT specification 41
Table 5-7: Connector contact identification.....43
Table 5-8: Cable assembly Type A signal wire connections 47
Table 5-9: Cable assembly Type AL signal wire connections 49
Table 5-10 Example calculation of maximum bit rate.....61
Table 5-11: Address function.....99