

# ISO 5309:2023-12 (E)

## Civil small and light unmanned aircraft systems ( UAS) - Vibration test methods

---

<b>Contents</b>	<b>Page</b>
<b>Foreword</b> .....	<b>iv</b>
<b>Introduction</b> .....	<b>v</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>1</b>
<b>4 Types of vibration test</b> .....	<b>1</b>
4.1 Standard vibration test.....	1
4.2 Transportation vibration test.....	2
<b>5 Test conditions</b> .....	<b>2</b>
5.1 General.....	2
5.2 Conditions for standard vibration test.....	2
5.2.1 Random test.....	2
5.2.2 Sinusoidal test.....	3
5.2.3 Sine-on-random test.....	3
5.3 Conditions for transportation vibration test.....	6
5.3.1 Random test.....	6
5.3.2 Vehicle field test.....	7
5.4 Vibration test requirements and recommendations.....	7
5.5 Control level tolerance requirements.....	8
5.5.1 Random input control.....	8
5.5.2 Sinusoidal control.....	8
<b>6 Test procedure</b> .....	<b>8</b>
6.1 Random test.....	8
6.1.1 General.....	8
6.1.2 Check before test.....	8
6.1.3 Test article installation.....	8
6.1.4 Test process.....	9
6.1.5 Check after test.....	9
6.2 Sinusoidal test.....	9
6.2.1 General.....	9
6.2.2 Check before test.....	9
6.2.3 Test article installation.....	9
6.2.4 Test process.....	9
6.2.5 Check after test.....	10
6.3 Sine-on-random test.....	10
6.3.1 General.....	10
6.3.2 Check before test.....	10
6.3.3 Test article installation.....	10
6.3.4 Test process.....	10
6.3.5 Check after test.....	11
<b>7 Test report</b> .....	<b>11</b>
<b>Annex A (informative) Information to be given in the relevant functions</b> .....	<b>12</b>
<b>Bibliography</b> .....	<b>13</b>

