

# ISO 16412:2005-05 (E)

## Air cargo equipment - Air cargo pallets - Utilization guidelines

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>General requirements .....</b>	<b>3</b>
4.1	General .....	3
4.2	Mass .....	3
4.3	Area load .....	4
4.4	Running load .....	4
4.5	CG location (plan view) .....	4
4.6	CG location (height) .....	5
4.7	Contour .....	6
<b>5</b>	<b>Installation .....</b>	<b>6</b>
5.1	Condition check .....	6
5.2	Cargo stacking .....	7
5.3	Shifting protection .....	9
5.4	Net installation .....	9
<b>6</b>	<b>Shoring .....</b>	<b>10</b>
6.1	General .....	10
6.2	Methods .....	11
6.3	Computation .....	12
<b>7</b>	<b>Restraint .....</b>	<b>13</b>
7.1	Net restraint .....	13
7.2	Straps complement .....	13
7.3	Straps tie-down .....	14
<b>8</b>	<b>Specific commodities .....</b>	<b>14</b>
8.1	General .....	14
8.2	Overhangs .....	14
8.3	Long loads .....	15
8.4	"Tall" loads .....	16
8.5	Drums, cans, barrels .....	16
8.6	Reels, spools .....	16
8.7	Dangerous goods .....	17
<b>9</b>	<b>Pallet accessories .....</b>	<b>18</b>
9.1	Pallet covers .....	18
9.2	Pallet extenders .....	19
9.3	Pallet couplings .....	19
9.4	Other accessories .....	19
<b>10</b>	<b>Operator requirements .....</b>	<b>20</b>
10.1	General .....	20
10.2	Operating instructions .....	20
10.3	Training and qualification .....	21
10.4	Quality control .....	21
Bibliography .....		22