ISO 16412:2005-05 (E)

Air cargo equipment - Air cargo pallets - Utilization guidelines

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 2

4 General requirements 3
4.1 General 3
4.2 Mass 3
4.3 Area load 4
4.4 Running load 4
4.5 CG location (plan view) 4
4.6 CG location (height) 5
4.7 Contour 6

5 Installation 6
5.1 Condition check 6
5.2 Cargo stacking 7
5.3 Shifting protection 9
5.4 Net installation 9

6 Shoring 10
6.1 General 10
6.2 Methods 11
6.3 Computation 12

7 Restraint 13
7.1 Net restraint 13
7.2 Straps complement 13
7.3 Straps tie-down 14

8 Specific commodities 14
8.1 General 14
8.2 Overhangs 14
8.3 Long loads 15
8.4 "Tall" loads 16
8.5 Drums, cans, barrels 16
8.6 Reels, spools 16
8.7 Dangerous goods 17

9 Pallet accessories 18
9.1 Pallet covers 18
9.2 Pallet extenders 19
9.3 Pallet couplings 19
9.4 Other accessories 19

10 Operator requirements 20
10.1 General 20
10.2 Operating instructions 20
10.3 Training and qualification 21
10.4 Quality control 21

Bibliography 22