DIN EN 12312-15:2006-03 (E)

Aircraft ground support equipment - Specific requirements - Part 15: Baggage and equipment tractors

Contents

Page

page Foreword 3

Introduction 4

1 Scope 5

2 Normative references 5

3 Terms and definitions 6

4 List of significant hazards 6

5 Safety requirements and/or measures 6
5.1 General requirements 6
5.2 Driver's accommodation 7
5.3 Driver's cabin 7
5.4 Seats 8
5.5 Controls, monitoring devices and displays 8
5.6 Additional operating positions 8
5.7 Chassis and body 9
5.8 Electrical equipment 9

6 Information for use 9
6.1 Marking 9
6.2 Additional marking 9
6.3 Instructions 10

7 Verification of requirements 10

Annex A (informative) Examples of typical baggage and equipment tractors 11

Annex B (normative) List of hazards in addition to those of EN 1915-1 12

Annex C (normative) Minimum space envelope for seated operator enclosure 14

Annex D (informative) Examples of couplings 15

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive Machinery Directive 98/37/EC 17

Bibliography 18