ISO 1136:2015-03 (E)

Wool - Determination of mean diameter of fibres - Air permeability method

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Principle 1

5 Apparatus 2
5.1 Forms of apparatus 2
5.2 Detailed parts 2

6 Conditioning and testing atmosphere 4

7 Preparation of test specimens 4
7.1 Unopened sliver 4
7.1.1 Cleaning 4
7.1.2 Number of specimens 4
7.1.3 Selection of specimens 5
7.1.4 Specimen mass 5
7.1.5 Preparation 5
7.2 Opened sliver 5
7.2.1 Cleaning 5
7.2.2 Preparation 5
7.2.3 Number of specimens 5
7.2.4 Selection of specimens 5
7.2.5 Specimen mass 5

8 Procedure 6
8.1 Unopened sliver 6
8.2 Opened sliver 6

9 Expression of results 7

10 Test report 7

Annex A (informative) Calibration of apparatus 8

Annex B (informative) Reproducibility of results 11

Annex C (normative) Correction for relative humidity 12

Annex D (informative) Special types of wool 13

Annex E (informative) Reference slivers for calibration 14

Bibliography 15